



EMC[®] Secure Remote Support
Release 2.28

Site Planning Guide

REV 02

EMC Corporation
Corporate Headquarters:
Hopkinton, MA 01748-9103
1-508-435-1000
www.EMC.com

Copyright © 2005-2014 EMC Corporation. All rights reserved.

Published June, 2014

EMC believes the information in this publication is accurate as of its publication date. The information is subject to change without notice.

THE INFORMATION IN THIS PUBLICATION IS PROVIDED "AS IS." EMC CORPORATION MAKES NO REPRESENTATIONS OR WARRANTIES OF ANY KIND WITH RESPECT TO THE INFORMATION IN THIS PUBLICATION, AND SPECIFICALLY DISCLAIMS IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE.

Use, copying, and distribution of any EMC software described in this publication requires an applicable software license.

For the most up-to-date regulatory document for your product line, go to the Document/Whitepaper Library on the EMC Online Support Site (support.emc.com).

For the most up-to-date-listing of EMC product names, see EMC Corporation Trademarks on EMC.com. All other trademarks used herein are the property of their respective owners.

Preface

Chapter 1

Overview

About ESRS	16
ESRS components	18
Other components	18
Requirements for ESRS customers	19
Supported devices	20
Responsibilities for the ESRS components	24
Customer	24
EMC Global Services	25
Site planning process	25
Coordination with EMC	25

Chapter 2

Component Requirements

Basics	28
Server types	28
Server requirements	28
VMware/Hyper-V support for servers	33
VMware/Hyper-V requirements	33
VMware/Hyper-V examples	34
Network requirements	34
Enabling communication to EMC	35
Enabling proxy server for ESRS Client traffic to EMC	35
Communication between Policy Manager and ESRS Clients ..	36
Communication between the ESRS Clients and devices	37
Port Requirements	39

Chapter 3	Configurations	
	Introduction.....	48
	ESRS Gateway Client.....	48
	Policy Manager.....	48
	Device limits.....	49
	Recommended ESRS configurations.....	51
	High Availability Gateway Cluster and Policy Manager.....	51
	Single Gateway Client and Policy Manager.....	53
	Single Gateway Client server with co-located Policy Manager	54
	Other supported configurations.....	55
	High Availability Gateway Client servers without Policy	
	Manager.....	55
	Single Gateway Client server without Policy Manager.....	56
	Topology and network considerations.....	58
	Determining the quantity of Gateway Clients and Policy	
	Managers.....	58
	Installing a separate Policy Manager server.....	58
	Protecting the Gateway Client server.....	59
	Using proxy servers.....	59
	Topology configurations.....	60
	About the Policy Manager.....	64
	Redundant Policy Manager.....	64
	Policy Manager authorization settings.....	64
	Policy Manager failure.....	65
	About not using a Policy Manager.....	66
	About High Availability Gateway Clusters.....	67
	High Availability Gateway Cluster clients do not have	
	failover.....	68
	Failover behavior at the EMC device level.....	68
	About Single Gateway Client configurations.....	69
Chapter 4	Preparing for Site Installation	
	Overview.....	72
	Coordination with EMC.....	72
	Preparation work.....	72
	EMC coordination schedule.....	73
	Kickoff meeting.....	73
	Configuration planning and documentation meeting.....	77
	Installation planning and scheduling meeting.....	81
Appendix A	Pre-Site Checklist Example	

Contact information..... 84
Environment specifications..... 86
Checklist for installation visit readiness 87
Ports opened for Gateway Client operation..... 96

Glossary

Index

	Title	Page
1	ESRS architecture	17
2	Port diagram for generic EMC managed product.....	38
3	Clustered HA Gateway Client servers and Policy Manager	51
4	Single Gateway Client server and Policy Manager	53
5	Single Gateway Client server with co-located Policy Manager	54
6	High Availability Gateway Client servers without Policy Manager	55
7	Single Gateway Client server without Policy Manager.....	56
8	Gateway Client and Device Client / Management LAN configuration	61
9	Gateway Client and Device Client / Production network configuration...	62
10	Gateway Client and Device Client / DMZ configuration.....	63
11	Configuration Tool: Removing Policy Manager requirements	66

	Title	Page
1	Product and application releases supported by ESRS Clients.....	21
2	Gateway Client server requirements.....	29
3	Gateway Client server standard configuration requirements.....	30
4	Policy Manager server requirements	31
5	Co-located Gateway Client and Policy Manager server (for test only) ..	32
6	Port requirements for Gateway Client and Policy Manager servers.....	39
7	Port requirements for devices managed by Gateway Client.....	40
8	Gateway Client configuration examples for maximum devices	50

As part of an effort to improve and enhance the performance and capabilities of its product line, EMC from time to time releases revisions of its hardware and software. Therefore, some functions described in this guide may not be supported by all revisions of the software or hardware currently in use. For the most up-to-date information on product features, refer to your product release notes.

If a product does not function properly or does not function as described in this guide, please contact your EMC representative.

Audience

This guide is part of the EMC Secure Remote Support release 2.0 documentation set, and is intended for use by customers and prospective customers.

Readers of this guide are expected to be familiar with the following topics:

- ◆ Local network administration
- ◆ Internet protocols
- ◆ EMC storage system characteristics and administration

Related documentation

See the following documents for related information:

- ◆ *EMC Secure Remote Support Release Notes*
- ◆ *EMC Secure Remote Support Technical Description*
- ◆ *EMC Secure Remote Support Pre-Site Checklist*
- ◆ *EMC Secure Remote Support Port Requirements*
- ◆ *EMC Secure Remote Support Gateway for Windows Operations Guide*
- ◆ *EMC Secure Remote Support Customer Environment Check Tool for Windows Operations Guide*
- ◆ *EMC Secure Remote Support Gateway for Linux Operations Guide*

- ◆ *EMC Secure Remote Support Customer Environment Check Tool for Linux Operations Guide*
- ◆ *EMC Secure Remote Support Policy Manager Release 6.6 Operations Guide*

Conventions used in this guide

EMC uses the following conventions for notes, cautions, warnings, and danger notices.

Note: A note presents information that is important, but not hazard-related.



CAUTION

A caution contains information essential to avoid data loss or damage to the system or equipment.



IMPORTANT

An important notice contains information essential to operation of the software.

Typographical conventions

EMC uses the following type style conventions in this document:

Normal

Used in running (nonprocedural) text for:

- Names of interface elements (such as names of windows, dialog boxes, buttons, fields, and menus)
- Names of resources, attributes, pools, Boolean expressions, buttons, DQL statements, keywords, clauses, environment variables, filenames, functions, utilities
- URLs, pathnames, filenames, directory names, computer names, links, groups, service keys, file systems, notifications

Bold

Used in running (nonprocedural) text for:

- Names of commands, daemons, options, programs, processes, services, applications, utilities, kernels, notifications, system call, man pages

Used in procedures for:

- Names of interface elements (such as names of windows, dialog boxes, buttons, fields, and menus)
- What user specifically selects, clicks, presses, or types

Italic

Used in all text (including procedures) for:

- Full titles of publications referenced in text
- Emphasis (for example a new term)
- Variables

<code>Courier</code>	Used for: <ul style="list-style-type: none"> • System output, such as an error message or script • URLs, complete paths, filenames, prompts, and syntax when shown outside of running text
Courier bold	Used for: <ul style="list-style-type: none"> • Specific user input (such as commands)
<i>Courier italic</i>	Used in procedures for: <ul style="list-style-type: none"> • Variables on command line • User input variables
< >	Angle brackets enclose parameter or variable values supplied by the user
[]	Square brackets enclose optional values
	Vertical bar indicates alternate selections - the bar means “or”
{ }	Braces indicate content that you must specify (that is, x or y or z)
...	Ellipses indicate nonessential information omitted from the example

Where to get help

EMC support, product, and licensing information can be obtained as follows.

Product information — For documentation, release notes, software updates, or for information about EMC products, licensing, and service, go to the EMC Online Support Site (registration required) at:

<http://support.emc.com>

Technical support — For technical support, click Support by Product on the EMC Online Support Site. To open a service request through support.emc.com, you must have a valid support agreement. Please contact your EMC sales representative for details about obtaining a valid support agreement or to answer any questions about your account.

Your comments

Your suggestions will help us continue to improve the accuracy, organization, and overall quality of the user publications. Please send your comments regarding this document to:

techpubcomments@EMC.com

This chapter introduces EMC Secure Remote Support so that you can begin to make decisions about the configuration that will best fit your requirements and environment.

It also provides an overview of the process for working with EMC Global Services to prepare your site for your ESRS implementation.


Topics include:

- ◆ About ESRS 16
- ◆ Supported devices 20
- ◆ Responsibilities for the ESRS components 24
- ◆ Site planning process 25

About ESRS

EMC[®] Secure Remote Support (ESRS) is an IP-based automated connect home and remote support solution enhanced by a comprehensive security system. ESRS creates both a unified architecture and a common point of access for remote support activities performed on your EMC products. For an illustration of the ESRS architecture, see [Figure 1 on page 17](#).

Note: *EMC Secure Remote Support Technical Description* (available on the EMC EMC Online Support Site (support.emc.com)) provides details on how your site ESRS architecture performs and communicates with the EMC enterprise.



GEN-002137

Figure 1 ESRS architecture

ESRS components

ESRS includes the following components at your site:

Gateway Client(s) — This ESRS software component is installed on a customer-supplied dedicated server or VMware instance. It can also be installed on multiple servers. The servers act as the single point of entry and exit for all IP-based remote support activities and most EMC connect home notifications.

Embedded ESRS Device clients — This ESRS software component is integrated on some EMC Products and utilise the same technology as the ESRS Gateway Client. If the Embedded ESRS Device Client is utilized the device is not managed by and ESRS Gateway Client. The the Embedded ESRS Device Client can also use the same or a different Policy Manager as an ESRS Gateway Client and enforces the policy, and audits just like an ESRS Gateway Client but only on that specific device.

Policy Manager — This ESRS software component is installed on a customer-supplied server or servers. It can be configured to control remote access to your devices and maintain an audit log of remote connections, file transfers connect homes) by the ESRS Clients, and access to and administration actions performed on the Policy Manager.

Other components

EMC Secure Remote Support builds upon previous releases by providing many new features for remote notification and support.

Application installation

A Provisioning Tool is provided on a CD or can be downloaded from support.emc.com. The tool is used to initiate the installation process and download the most recent versions of the ESRS Client application from EMC.

Deployment and configuration

ESRS provides a Configuration Tool that is used after software installation for various activities including:

- ◆ Viewing connectivity status between the ESRS Client and EMC
- ◆ Viewing connectivity status between the ESRS Client and Policy Manager
- ◆ Viewing connectivity status between the ESRS Client and Managed Devices
- ◆ Initiating device deployment requests
- ◆ Initiating device removal requests

- ◆ Processing managed device update requests
- ◆ View history of Deployment / UnDeployment or edit requests of devices
- ◆ Configuring or changing the ESRS Client for use with a Proxy Server
- ◆ Configuring communication between the Policy Manager and the ESRS Client
- ◆ Configuring or changing the ESRS Client for Proxy Server for the Policy Manager (if needed)
- ◆ Viewing status of Watchdog, ESRS Gateway Client and Listener Services, and SRS Gateway Proxy Services
- ◆ View only of active Remote Access Connection through the ESRS Gateway Client
- ◆ View ESRS Gateway Client Configuration Tool (CT) logs

Note: The Windows version uses a GUI, the Linux version is command line only.

Redundant Policy Manager option

ESRS provides the option to install a redundant Policy Manager. If the primary Policy Manager becomes unavailable, the redundant Policy Manager is used to resume operations. Both Policy Managers enforce the same policies. Manual failover is required.

Note: Redundant Policy Manager is only supported on Policy Manager 2.02.1-xxx.

Security enhancements

ESRS provides the enhanced security practices and encryption technologies, including:

- ◆ Certificate protected by RSA Lockbox Technology
- ◆ Advanced Encryption Standard (AES), SHA-1, 256-bit encryption between the Gateway Client and EMC
- ◆ Bilateral certificate authentication for all communication between the Client and EMC
- ◆ Configurable security between ESRS components

Requirements for ESRS customers

ESRS customers must provide the following:

- ◆ An IP network with Internet connectivity

- ◆ The capability to add Gateway Client servers and Policy Manager servers to your network
- ◆ Network connectivity between the servers and EMC devices to be managed by ESRS
- ◆ Internet connectivity to EMC's ESRS infrastructure by using outbound ports 443 and 8443



IMPORTANT

Port 8443 is not required for functionality, however without this port being opened, there will be a significant decrease in remote support performance, which will directly impact time to resolve issues on the end devices.

- ◆ Network connectivity between ESRS Client(s) and Policy Manager

For additional requirements, see [“Responsibilities for the ESRS components”](#) on page 24.

Supported devices

[Table 1 on page 21](#) lists the EMC storage device models and environments supported by ESRS IP.

If you need to upgrade one or more of your EMC devices so that they are compatible with ESRS IP, you must contact EMC Global Services and schedule the device upgrades to occur *before* you have those devices added to your ESRS managed device list.

Once the devices have been upgraded, you can have them added to the managed device list during or after the ESRS installation. Upgrades to EMC products may be billed separately from the ESRS installation.

Note: Upgrades to service processors or device code are *not* included as part of the ESRS implementation.

Table 1 Product and application releases supported by ESRS Clients

Product	Environment/application releases	Minimum ESRS Client Code Supported
EMC Atmos [®]	Atmos 1.4 or later	2.06
EMC Avamar [®]	Avamar 6.0 or later	2.06
EMC Celerra [®]	NAS Code 5.4 or later	2.02
EMC Centera [®]	CentraStar [®] 2.4 or later ^b	2.02
EMC CLARiiON [®] CX, CX3, CX4, and AX4-5 Series storage systems (<i>distributed or Enterprise environments</i>)	FLARE [®] Operating Environment 2.19 or later Navisphere [®] Manager 6.19 or later Note: The AX-100/AX-150 are not supported as they do not support the required CLARAlert. The AX4-5 series are supported only if the Navisphere Full license (with CLARAlert) is purchased and installed on the storage system.	2.02
EMC Connectrix [®] Manager (CM) managing Connectrix M-series switches	Connectrix Manager 7.x with DialEMC 2.2.10, or Connectrix Manager 8.x or later with ConnectEMC 1.x	2.02
Connectrix Manager (CM) managing Connectrix M-series and B-series switches	Connectrix Manager 9.6.2 or later with ConnectEMC 1.x ^e	2.02
Connectrix Manager Data Center Edition (CMDCE) managing Connectrix M-series and B-series switches	Connectrix Manager Data Center Edition 10.1.1 or later with ConnectEMC 4.0.2 ^f	2.02
Connectrix Manager Converged Network Edition (CMCNE) managing Connectrix M-series and B-series switches	Connectrix Manager Converged Network Edition 11.1.1 or later with ConnectEMC 5.0.2.8 or later	2.02
Data Domain	DD OS version 4.8 or higher	2.14
EMC Disk Library for mainframe (DLm), Gen2	DLm 4020, DLm 4080, release 1.2 and later	2.02
EMC Disk Library for mainframe (DLm), Gen3	DLm 8000 3.4.0 & 3.4.1	2.18
	DLm 6000 All releases	2.16
	DLm 2000 All releases	2.12
	DLm 1000 3.5	2.22
EMC Disk Library for mainframe (DLm), Gen4	DLm 8100, 2100V, and 2100D	2.24
EMC Disk Library (EDL)	DL-5100 and 5200 series DL-4000 series — DL-4100, DL-4106, DL-4200, DL-4206, DL-4400A/B, DL-4406A/B DL-700 series — DL-710, DL-720, DL-740 DL-310 DL3D 1500, 3000, 4000 — release 1.01 and later	2.02
EMC Greenplum [®] Data Computing Appliance (DCA)	Greenplum 4.0	2.12

Table 1 Product and application releases supported by ESRS Clients

Product	Environment/application releases	Minimum ESRS Client Code Supported
EMC Invista®	Invista 2.2 or later	2.02
EMC Isilon®	OneFS 7.1	2.24
EMC RecoverPoint	RecoverPoint 3.1, 3.2, 3.3, 3.4 and later ^a	2.02
EMC Symmetrix® 8000 Series	Enginuity™ 5567 and 5568 with Service Processor Part Number ^c 090-000-064, 090-000-074, or 090-000-09x	2.02
Symmetrix DMX™ Series	Enginuity 5670, 5671	2.02
Symmetrix DMX-3 Series	Enginuity 5771, 5772, 5773	2.02
Symmetrix DMX-4 Series	Enginuity 5772, 5773	2.02
Symmetrix VMax™ Series	Enginuity 5874, 5875	2.02
Symmetrix Device Client	Enginuity 5670, 5671, 5771, 5772, 5773, 5874, 5875	2.00
EMC ViPR®	Contact your EMC representative	2.22
EMC VMAX Cloud Edition (CE)	Contact your EMC representative	2.22
Switch - Fabric Manager managing Brocade B-series switches	<ul style="list-style-type: none"> Brocade B-series switches running Fabric OS 5.0.1b through 6.1.0x only, with Fabric Manager 5.2.0b or later^{b d e g} Brocade switches without monitoring (connect in support only, no connect home) 	2.02
Switch - Cisco	<ul style="list-style-type: none"> Cisco MDS switches running SAN-OS 3.1(2) or later, NX-OS 4.1(1b) or later.^b Nexus switches running NX-OS 4.2(1)N1(1) or later.^{b h} <p>Note: MDS switches require Fabric Manager or Cisco Data Center Network Manager (DCNM) to be the same version or higher than the highest switch firmware version. Nexus requires Fabric Manager 5.0(1a) or higher.</p>	2.02
EMC VNX®	VNX Operating Environment (OE) for Block 05.31.000.5.006 or greater VNX Operating Environment (OE) for File 7.0.12.0 or greater	2.08
VNX Control Station Device Client	VNX Operating Environment (OE) for Block 05.31.000.5.006 or greater VNX Operating Environment (OE) for File 7.1.44 or greater	2.18
EMC VNXe®	VNXe 2.0.x	2.08
VNXe Device Client	VNXe 2.0.x	2.08
EMC VPLEX®	GeoSynchrony 4.0.0.00.00.11 or later	2.04

Table 1 Product and application releases supported by ESRS Clients

Product	Environment/application releases	Minimum ESRS Client Code Supported
EMC XtremIO®	XtremIO 2.2.x and greater	2.22
XtremIO Device Client	XtremIO 2.2.x and greater	2.24

- a. RecoverPoint 3.1 and 3.2 utilize ESRS for remote support access only. RecoverPoint 3.3 and later add the connect home feature.
RecoverPoint Management GUI (RPMAGUI) is supported on Gateway Client code 2.20 and above
- b. For remote support access only, not for connect home through ESRS IP.
- c. These part numbers designate Service Processor that is running Windows NT SP6. xx70 code only supports ftp for connect home.
- d. Fabric Manager does not support FOS 6.1.1 or higher. CM or CMDCE is required. Please refer to the appropriate FOS Release Notes.
- e. CM does not support FOS 6.3.x or higher. cmdce is required. Please refer to the appropriate FOS Release Notes.
- f. CMDCE is required to support FOS 6.3.x or higher. Please refer to the appropriate FOS Release Notes.
- g. Connect home via CM, CMDCE, or CMCNE, otherwise no connect home through ESRS Client.
- h. Connect home via Cisco Fabric Manager or Cisco Data Center Network Manager, otherwise no connect home through ESRS Client.

Responsibilities for the ESRS components

This section defines who is responsible for various ESRS tasks including installation, configuration, operation, and maintenance.

Customer

The EMC customer is responsible for the following tasks:

- ◆ Maintaining internet connectivity
- ◆ Preparing and configuring the network, Proxy Server, and firewall
- ◆ Preparing the servers for installation. This includes:
 - Preparing the Gateway Client server hardware and operating system
 - Preparing the Policy Manager server hardware and operating system
 - Placing the Gateway Client and Policy Manager servers on the IP network
 - Maintaining Network Connectivity between Gateway Client and EMC
 - Maintaining Network Connectivity between Gateway Client and Managed Devices
 - Maintaining Network Connectivity between Gateway Client and Policy Manager
 - Maintain OS patches / updates for Gateway and Policy Manager servers
 - Installing and maintaining antivirus and other applicable security software on the servers
 - Configuring, administering, and updating policy management activities, policies, and accounts on the Policy Manager
 - Backing up and restoring file systems
 - Providing continuing maintenance, including security and operating system updates and upgrades on the Gateway Client and Policy Manager servers
 - Providing physical security of all hardware
 - Protecting all files on the servers, including the SSL certificate, if applicable

EMC Global Services

EMC Global Services personnel are responsible for the following tasks:

- ◆ Installing the ESRS Gateway Client software and Simple Implementation Policy Manager software
- ◆ Configuring and deploying EMC product managed devices
- ◆ Updating the ESRS Client and Simple Implementation Policy Manager software

Note: Policy Manager is customer installable and configurable.

Site planning process

EMC Secure Remote Support requires customer-provided and EMC-provided components and actions. Your network, storage system, and security administration personnel must work closely with your EMC Global Services representatives to prepare your site for ESRS software installation.

This guide provides detailed instructions for completing each step in the customer site planning process. You should plan your solution deployment on a schedule that you have coordinated with your EMC Global Services professional.

Coordination with EMC

This is a recommended schedule of preparation coordination meetings and activities with EMC and your internal network, storage, and security teams:

- ◆ Your teams should meet with EMC Sales and EMC Global Services to receive an ESRS review and get answers to your initial questions.
- ◆ You should host an onsite meeting for EMC Global Services and your teams to finalize and record your ESRS system configuration.
- ◆ Your teams should meet with EMC Global Services to finalize the solution deployment schedule and details.

For additional details about these meetings, see [Chapter 4, "Preparing for Site Installation."](#)

Component Requirements

This chapter describes the requirements for the ESRS Clients, server hardware, and software that you must supply as part of the total configuration. Topics include:

- ◆ Basics 28
- ◆ Server requirements..... 28
- ◆ VMware/Hyper-V support for servers 33
- ◆ Network requirements 34

Basics

To properly support the ESRS configuration you choose, EMC recommends that you become familiar with the requirements of each software and hardware component. This chapter provides the requirements of each component.



IMPORTANT

Be sure to read [Chapter 3, “Configurations,”](#) to define your configuration type and determine if you will need additional servers.

Server types

Depending on your chosen configuration, you must supply:

- ◆ At least one Gateway Client server (two or more servers are required for a High Availability configuration). Servers can be dedicated or virtual.
- ◆ A Policy Manager server, which can be dedicated, virtual, or co-located with a Gateway Client server. Recommend for test purposes only; not recommended for Production environments.

Note: Detail on virtual servers are provided in [“VMware/Hyper-V support for servers” on page 33.](#)

For detailed server requirements, refer to the tables in [“Server requirements” on page 28.](#)

To verify that your servers meet the hardware and software requirements of ESRS, you must obtain a copy of the Customer Environment Check Tool (CECT) from your EMC Global Services professional or download from the EMC Online Support Site (support.emc.com). Install and run the tool on each server before installation of the Gateway Client and Policy Manager software on the servers. The *EMC Secure Remote Support Customer Environment Check Tool Operations Guide* provides instructions on how to use the CECT.

Server requirements

Servers must meet the hardware and operating system requirements listed in [Table 2 on page 29](#) through [Table 5 on page 32.](#)

Table 2 Gateway Client server requirements

Hardware	Software	Notes
<p>Processor — One or more processors, minimum 2.2 GHz, must support SSE2 instruction set (required for FIPS compliance)</p> <p>Free Memory — Minimum 1 GB of RAM, preferred 2 GB of RAM</p> <p>Comm — Minimum single 10/100 Ethernet adapter (may require dual 10/100 Ethernet depending on customer network configuration and environment), preferred Gigabit Ethernet adapters, optional additional NIC for data backups</p> <p>Free Disk Space — Minimum 1GB available for installation (preferably on a storage device of 40 GB or larger for operation)</p> <p>VMware/Hyper-V server For more information, see “VMware/Hyper-V support for servers” on page 33</p> <p>Note: Contact EMC Global Services if your configuration does not meet the minimum hardware requirements.</p>	<p>Operating system — One of the following (US English only supported):</p> <ul style="list-style-type: none"> • Windows Server 2003 R1, 32-bit or 64-bit, SP1, SP2 or SP3 • Windows Server 2003 R2, 32-bit or 64-bit, SP1, SP2 or SP3 • Windows Server 2008 R1, 6.0, 32-bit or 64-bit, IIS 7.0, SP1 or SP2 (IIS 6 Compatibility) • Windows Server 2008 R1, 6.0, 32-bit or 64-bit, IIS 7.0, SP1 or SP2 w/ IIS 7.5 FTP Add-in • Windows Server 2008 Enterprise R1, 6.0, 32-bit or 64-bit, IIS 7.0, SP1 or SP2 (IIS 6 Compatibility) • Windows Server 2008 Datacenter R1, 6.0, 32-bit or 64-bit, IIS 7.0, SP1 or SP2 (IIS 6 Compatibility) • Windows Server 2008 R2, 6.1, 64-bit only, IIS 7.0/7.5, SP1 or SP2 • Windows Server 2008 R2 Enterprise 64-bit IIS 7.0/7.5, SP1 or SP2 • Windows Server 2008 R2 Datacenter 64-bit IIS 7.0/7.5, SP1 or SP2 • Windows Server 2012 R1 Foundation 64-bit IIS 8.0 • Windows Server 2012 R1 Standard 64-bit IIS 8.0 • Supported French and Japanese OS (Windows 2008 R1 and R2) with English language pack • Red Hat Enterprise Linux 6.2 (32-bit) • CentOS release 6.4, 32-bit • Hyper-V and VMware ESX 2.5.x or above running: <ul style="list-style-type: none"> – Windows Server 2008 Standard 32-bit – Windows Server 2008 Enterprise 32-bit – Windows Server 2008 Datacenter 32-bit – Windows Server 2008 R2 Standard 64-bit – Windows Server 2008 R2 Enterprise 64-bit – Windows Server 2008 R2 Datacenter 64-bit – Red Hat Enterprise Linux 6.2 (32-bit) – CentOS release 6.4, 32-bit <p>Microsoft .NET Framework Version 2.0 with SP1(minimum) or Microsoft .NET Framework 3.5 is required. NOTE: Microsoft.NET Framework 4.0 is not compatible at this time.</p> <p>Microsoft Visual C++ 2005 SP1 Runtime Library installed</p> <p>Microsoft Internet Information Services (IIS) installed on system drive</p> <p>IIS FTP and SMTP services enabled and configured as specified in Table 3 on page 30</p> <p>EMC OnAlert™ and ESRConfig user accounts created and configured as specified in Table 3 on page 30</p> <p>Remote Desktop installed If EMC needs to remotely access a desktop to verify ESRs configuration or to troubleshoot, EMC will contact you for a WebEx session and ask you to establish a Remote Desktop session to the Gateway or Policy Manager.</p>	<p>Topology, see Chapter 3, “Configurations”:</p> <ul style="list-style-type: none"> • Two servers are required for a High Availability configuration. • The ESRs software must reside on a dedicated server. <p>You may harden the Windows OS to meet network security requirements, as long as the hardened servers:</p> <ul style="list-style-type: none"> • Meet ESRs OS requirements (at left). • Meet network configuration requirements. See “Network requirements” on page 34. • Do not inhibit normal installation or operation of the ESRs Client and/or Utilities. <p>Note: Support for ESRs Gateway on Windows Server 2003 will be deprecated in the near future.</p> <p>Note: Windows Server 2012 must be GUI mode to install the ESRs Gateway.</p> <p>Note: Linux Gateways are command line only. No GUI.</p>

Table 3 Gateway Client server standard configuration requirements

Category	Variable	Value
Internet Information Services (IIS)	Startup type State	Manual Started
<p>Note: The following settings describe the FTP services and directory structure required for Gateway Client server installation. Once the server has been installed, the FTP or SMTP <i>services</i> may be disabled (one or the other, but not both). However, the FTP directory <i>structure</i> must remain in place.</p>		
Default FTP Site > Properties		
FTP Site	Description IP address TCP port	ESRS Gateway FTP Site Local IP <Internal> 21
Security Accounts	Allow anonymous connections	No (unchecked)
Home Directory	Local path Read Write Log visits User Isolation	<install_drive>\EMC\ESRS\Gateway\work\ftproot Yes (checked) Yes (checked) Yes (checked) Yes
Default SMTP Virtual Server > Properties		
	Description Domain Drop directory Email message	ESRS Gateway SMTP Site emc.com <install_drive>\EMC\ESRS\Gateway\work\mailroot\Drop maximum size of 15 MB
Local Users and Groups > New User		
	Default User Group	Yes
New User (1)	Username Password User must change password at next logon Password never expires	OnAlert EMCCONNECT (<i>case-sensitive</i>) No (unchecked) Yes (checked)
New User (2)	Username Password User must change password at next logon Password never expires	ESRSConfig esrsconfig (<i>case-sensitive</i>) No (unchecked) Yes (checked)
New directory		<install_drive>\EMC\ESRS\Gateway\work\mailroot\Badmail
<p>Notes:</p> <ul style="list-style-type: none"> <install_drive>\EMC\ESRS\Gateway\work\ftproot; <install_drive>\EMC\ESRS\Gateway\work\mailroot\Drop; and <install_drive>\EMC\ESRS\Gateway\work\mailroot\BadMail are configured in IIS after Gateway software is installed. Installation of IIS also requires the installation of the Management Consoles and Administrative Scripts (adsutilso.vbs). 		

Table 4 Policy Manager server requirements

Hardware	Software	Notes
<p>Processor — One or more processors, each 2.1 GHz or better</p> <p>Free memory — Minimum 2 GB RAM, preferred 3 GB RAM</p> <p>Comm — Minimum single 10/100 Ethernet adapter (may require dual 10/100 Ethernet adapters depending on customer network configuration and environment), preferred one Gigabit Ethernet adapter, optional additional NIC for data backups</p> <p>Free Disk Space — Minimum 2 GB available (preferably on a storage device of 80 GB or larger)</p> <p>Vmware server For more information, see “VMware/Hyper-V support for servers” on page 33</p>	<p>Operating system — One of the following: (US English only supported)</p> <ul style="list-style-type: none"> • Windows XP, SP2 or later • Windows Vista • Windows 7 • Windows 8 • Windows Server 2003 R1, 32-bit or 64-bit, SP1, SP2 or SP3 • Windows Server 2003 R2, 32-bit or 64-bit, SP1, SP2 or SP3 • Windows Server 2008 R1, 6.0, 32-bit or 64-bit, SP1 or SP2 • Windows Server 2008 R1, 6.0, 32-bit or 64-bit, SP1 or SP2 • Windows Server 2008 R2, 6.1, 64-bit only, SP1 or SP2 • Supported Japanese OS (Windows 2008 R1 and R2) with English language pack • Windows Server 2012 R1 Foundation 64-bit IIS 8.0 • Windows Server 2012 R1 Standard 64-bit IIS 8.0 • Redhat 6.4 (32-bit and 64-bit) • CentOS 6.4 (32-bit and 64-bit) • SUSE Linux Enterprise 11 SP2 (64-bit) <p>Microsoft .NET Framework Version 2.0 with SP1 (minimum) or Microsoft .NET Framework 3.5 is required if you are using the Customer Environment Check Tool (CECT) to validate that the PM server is setup correctly to install the PM software. NOTE: Microsoft .NET Framework 4.0 is not compatible at this time.</p> <p>Microsoft Windows Task Scheduler running and unrestricted</p> <p>Remote Desktop installed</p> <p>If EMC needs to remotely access a desktop to verify ESRS configuration or to troubleshoot, EMC will contact you for a WebEx session and ask you to establish a Remote Desktop session to the Gateway or Policy Manager.</p>	<p>Topology, see Chapter 3, “Configurations”:</p> <ul style="list-style-type: none"> • Policy Manager use is optional, but strongly recommended. • In an HA configuration, two dedicated servers required for ESRS software and one server for Policy Manager <p>You may harden Windows OS to meet network security requirements, as long as the hardened servers:</p> <ul style="list-style-type: none"> • Meet ESRS OS requirements (at left). • Meet Network configuration requirements. See “Network requirements” on page 34. • Do not inhibit normal installation or operation of the ESRS Client and /or Utilities. <p>Policy Manager software may reside on a shared server. However, there are some restrictions; contact your EMC Global Services representative with questions. Following are two examples:</p> <ul style="list-style-type: none"> • Policy Manager cannot be on same server as EMC ControlCenter. • There may be conflicts if the Policy Manager resides on a server with an application that uses the Tomcat web server, or with any applications that use port 8090 or 8443. <p>Note: Support for Policy Manager on Windows Server 2003 will be deprecated in the near future.</p>
<p>Notes:</p> <ul style="list-style-type: none"> • Disk space will be consumed due to audit logging. Ensure that adequate disk space is maintained. Contact EMC Global Services if your configuration does not meet the minimum hardware requirements. • Failure to maintain sufficient disk space may result in the Policy Manager becoming unavailable and/or in the corruption of the Policy Manager database, which could impact remote support and connect home notifications and may result in having to uninstall and re-install the Policy Manager application to recover functionality. 		

Table 5 Co-located Gateway Client and Policy Manager server (for test only)

Hardware	Software	Notes
<p>Processor — One or more processors, minimum 2.2 GHz, must support SSE2 instruction set (required for FIPS compliance)</p> <p>Free memory — 3 GB RAM</p> <p>Comm — Minimum single 10/100 Ethernet adapter (may require dual 10/100 Ethernet adapters depending on customer network configuration and environment), preferred dual Gigabit Ethernet adapters, optional additional NIC for data backups</p> <p>Free disk space — Minimum 3 GB available (preferably on a storage device of 80 GB or larger)</p> <p>VMware server For more information, see “VMware/Hyper-V support for servers” on page 33</p>	<p>Operating system — One of the following: (US English only supported)</p> <ul style="list-style-type: none"> Windows Server 2003 R1, 32-bit or 64-bit, IIS 6.0, SP1, SP2 or SP3 Windows Server 2003 R2, 32-bit or 64-bit, IIS 6.0, SP1, SP2 or SP3 Windows Server 2008 R1, 6.0, 32-bit or 64-bit, IIS 7.0, SP1 or SP2 (IIS 6 Compatibility) Windows Server 2008 R1, 6.0, 32-bit or 64-bit, IIS 7.0, SP1 or SP2 w/ IIS7.5 FTP Add-in Windows Server 2008 R2, 6.1, 64-bit only, IIS 7.0/7.5, SP1 or SP2 Supported Japanese OS (Windows 2008 R1 and R2), IIS requirements as above, with English language pack <p>Microsoft .NET Framework Version 2.0 with SP1 (minimum) or Microsoft .NET Framework 3.5 is required. NOTE: Microsoft.NET Framework 4.0 is not compatible at this time.</p> <p>Microsoft Visual C++ 2005 SP1 Runtime Library</p> <p>Microsoft Internet Information Services (IIS) installed on system drive</p> <p>IIS FTP and SMTP services enabled and configured as specified in Table 3 on page 30</p> <p>EMC OnAlert and ESRSConfig user accounts created and configured as specified in Table 3 on page 30</p> <p>Windows Task Scheduler running and unrestricted</p> <p>Remote Desktop installed</p> <p>If EMC needs to remotely access a desktop to verify ESRS configuration or to troubleshoot, EMC will contact you for a WebEx session and ask you to establish a Remote Desktop session to the Gateway or Policy Manager.</p>	<p>Topology, see Chapter 3, “Configurations”:</p> <ul style="list-style-type: none"> Server dedication to only the ESRS software plus the Policy Manager software is required. <p>You may harden Windows OS to meet network security requirements, as long as the hardened servers:</p> <ul style="list-style-type: none"> Meet ESRS OS requirements (at left). Meet Network configuration requirements. See “Network requirements” on page 34. Do not inhibit normal installation or operation of the ESRS Client and /or Utilities. <p>Policy Manager software may reside on a shared server. However, there are some restrictions—contact your EMC Global Services representative with questions. Following are two examples:</p> <ul style="list-style-type: none"> Policy Manager cannot be on the same server as EMC ControlCenter. There may be conflicts if the Policy Manager resides on a server with an application that uses the TomCat web server, or with any applications that use port 8090 or 8443.
<p>Notes:</p> <ul style="list-style-type: none"> Disk space will be consumed due to audit logging. Ensure that adequate disk space is maintained. Contact EMC Global Services if your configuration does not meet the minimum hardware requirements. Failure to maintain sufficient disk space may result in the Gateway and /or Policy Manager becoming unavailable and/or in the corruption of the Policy Manager database, which could impact remote support and connect home notifications and may result in having to uninstall and re-install the Policy Manager application to recover functionality. 		

VMware/Hyper-V support for servers



IMPORTANT

Do not place VMware/Hyper-V images or storage files on EMC devices managed by the Gateway Client.

ESRS Gateway Client is qualified to run on a VMware or Hyper-V virtual machine. VMware support enables you to use your existing VMware/Hyper-V infrastructure to benefit from the security features of the Gateway Client without adding hardware. VMware VMotion functionality also allows the Policy Manager, when installed in a virtual machine, to be moved from one physical server to another with no impact to remote support.



IMPORTANT

When running clustered HA Gateway Clients on VMware/Hyper-V, each Gateway Client must be located on different physical hardware.



IMPORTANT

Installation of the VMware/Hyper-V instance and operating system are the customer's responsibility.

Note: Policy Manager has not yet been qualified for support on Hyper-V.

Note: P2V Utility cannot be used to convert Physical server to Virtual server due to RSA LockBox Technology.

Note: VMotion cannot be used for the ESRS Client due to RSA LockBox Technology.

VMware/Hyper-V requirements

VMware servers must be version ESX 2.52 and later.

Minimum requirements:

- ◆ 15 GB partition

- ◆ 2.2 GHz virtual CPU
- ◆ 512 MB memory allocated (2 GB recommended, 3GB preferred)

Note: EMC strongly recommends that virtual hosts meet the same hardware and OS recommendations as for physical hardware so as to minimize performance issues.

Optional components:

- ◆ SMB modules
- ◆ VMotion functionality (for Policy Manager only, and cannot be used for the ESRS Client due to RSA LockBox Technology)

Note: The customer MUST be aware the over provisioning of the underlying VMware ESX/Hyper-V infrastructure may have significant negative impact on the operation and functionality of ESRS.

VMware/Hyper-V examples

Scenario 1

Two physical ESX servers with three VMware partitions—two on the first server and one on the second server. The first server hosts a Gateway Client and the Policy Manager. The second server hosts another Gateway Client. This enables you to put applications on the same server that normally would not be co-located.

Scenario 2

Three or more physical servers in an existing VMware environment. You install two or more Gateway Clients and Policy Manager on any of the existing physical servers, independent of physical location.

Network requirements

Before EMC Secure Remote Support goes online, you must ensure your network meets the following requirements:

- ◆ Port Address Translation (PAT) cannot be used for the IP addresses of any EMC devices managed by the ESRS.
- ◆ Dynamic IP addresses (DHCP) should not be used for any components of the ESRS Gateway Client servers, Policy Manager servers, or managed devices.

Note: If you use DHCP to assign IP addresses to any ESRS components (Gateway Client servers, Policy Manager, or managed devices), they must have “permanent reservation” IP addresses. Leases for the IP addresses that EMC devices use cannot be set to expire. EMC recommends that you assign static IP addresses to those devices you plan to have managed by ESRS.

- ◆ Routes must exist from each of your managed devices to each of your ESRS Clients.
- ◆ The Policy Manager must be reachable by all ESRS Clients.

Enabling communication to EMC

All communication between the EMC devices at your site and EMC Global Services is initiated by, and occurs through, a ESRS Client at your site over the outbound default port 443 and/or 8443. Your firewall administrators must open port 443 and 8443 *outbound* to enable communication between EMC and the ESRS Clients.



IMPORTANT

Port 8443 is not required for functionality, however without this port being opened, there will be a significant decrease in remote support performance, which will directly impact time to resolve issues on the end devices.

Enabling proxy server for ESRS Client traffic to EMC

ESRS supports the use of a proxy server for routing outbound Internet traffic from the ESRS Clients to EMC.

If you use a proxy server for outbound Internet traffic, you must make sure the proxy server:

- ◆ Can communicate with the ESRS Clients over an agreed-upon port.
- ◆ Can communicate with EMC, outbound, over SSL port 443 and 8443.



IMPORTANT

To maintain communication integrity, proxy servers and devices external to your DMZ must not perform any method of SSL checking on outbound IP traffic.

Note: The customer is responsible for all Proxy Server configuration. User account(s) should be service accounts that do not have expiring passwords.

The following proxy servers have been tested for use with ESRS. Note that configuration and operation are your responsibility.

- ◆ Linux Squid (supported in Red Hat 6.1 and 6.2)
- ◆ Apache HTTP Server release 1.1 and later (contains mod_proxy module)
- ◆ Microsoft ISA
- ◆ Netscape iPlanet Proxy Server release 3.6
- ◆ DeleGate 7_9_3

ESRS supports the following protocols for use with a proxy server:

- ◆ HTTP Proxy releases 1.0 and 1.1 (Username/Password is optional. If a username is provided a password is required)
- ◆ SOCKS releases 4 and 5 (may require username and password authentication)

Communication between Policy Manager and ESRS Clients

The Policy Manager application *only* responds to communication requests from the ESRS Clients.

At startup, the ESRS Client queries the Policy Manager and caches the permission rules. It must then periodically poll the Policy Manager for configuration updates and audit logging.

The Policy Manager is an HTTP listener. You must configure the Policy Manager and ESRS Client to use an agreed-upon port and protocol. EMC recommends that you use the port 8090 for standard HTTP, or port 8443 for SSL-enabled HTTPS. If necessary, you can specify a different port during the Policy Manager and ESRS Client installations.

Note: If you are running Policy Manager in a Windows Server 2008 environment, you must configure the Windows firewall to permit traffic to the Policy Manager on both ports 8090 (default) and 8443. The firewall is closed by default and must be specifically configured to permit the Policy Manager traffic.

Communication between the ESRS Clients and devices

There are two connection requirements between the ESRS Client and your managed devices:

- ◆ The first is the communication between the ESRS Client and your managed devices connections. The ESRS Client secures remote access connections to your EMC devices by using a session-based IP port-mapped solution.
- ◆ The second communication requirement is between your managed devices and the ESRS Client for connect home messages. For those devices that use the ESRS Client to forward connect home transfers, the transfer is sent through a secure encrypted data tunnel to EMC, an audit of the transfer is maintained on the Policy Manager.

Gateway Client

To enable communication between your Gateway Client and your devices, you must configure your internal firewalls to allow traffic over the specific ports shown in [Table 6 on page 39](#) and [Table 7 on page 40](#). These tables identify the installation site network firewall configuration open-port requirements for ESRS. The protocol/port number and direction are identified relative to EMC Gateway Client servers and storage devices. [Figure 2 on page 38](#) provides a representation of the connections between devices, the Gateway Client, and EMC.

Note: Some ports used by the Gateway Client servers and devices may be registered for use by other parties, or may not be registered by EMC. EMC is addressing these registration issues. In the meantime, be aware that all ports listed for use by Gateway Client servers and devices will be in use by the EMC applications listed.




Figure 2 Port diagram for generic EMC managed product

Port Requirements

Table 6 on page 39 lists the port requirements for the Gateway Client and Policy Manager servers. Table 7 on page 40 lists the port requirements for devices.

Table 6 Port requirements for Gateway Client and Policy Manager servers (page 1 of 2)

EMC product	TCP port or Protocol	Notes for port settings	Direction open	Source -or- Destination	Application name	Communication (network traffic) type	Performed by authorized EMC Global Services personnel: Support objective (frequency)
Gateway Client	HTTPS 443	See Primus emc238467, "What IP addresses are used by the EMC Secure Remote Support IP Solution." You can access this Primus on support.emc.com.	Outbound	to EMC	Client service	Service notification, setup, all traffic except remote support	N/A
	HTTPS 443 and 8443	See Primus emc238467, "What IP addresses are used by the EMC Secure Remote Support IP Solution." You can access this Primus on support.emc.com.	Outbound	to EMC Global Access Servers (GAS)	Client service	Remote support	N/A
	IMPORTANT: Port 8443 is not required for functionality, however without this port being opened, there will be a significant decrease in remote support performance, which will directly impact time to resolve issues on the end devices.						
	HTTPS 443	Use of HTTPS for service notifications inbound is dependent on the version of ConnectEMC used by the managed device. Refer to product documentation.	Inbound	from Managed device (EMC product)	ESRSHTTP	Service notification from device	N/A
	Passive FTP ports: 21, 5400–5413	During ESRS-installer execution, the value for Passive Port Range in IIS FTP is set to 21 and 5400 through 5413. This range indicates the data channel ports available for response to PASV commands. See RFC 959 for passive FTP definition. These ports are used for passive mode FTP of connect home messages as well as for the GWExt loading and output. GWExt uses HTTPS by default but can be configured to use HTTP.			Windows-GW: Microsoft IIS FTP		
					Linux-GW: vsftpd		
	SMTP 25		Windows-GW: Microsoft IIS SMTP	Linux-GW: postfix			
IMPORTANT: When opening ports for devices in Table 7, also open the same ports on the Gateway Client server , identified as "Inbound from Gateway Client server"			Outbound	to Managed device	Client service	Remote support for device	N/A
HTTP (configurable) Default = 8090		Outbound	to Policy Manager	Client service	Policy query	N/A	
HTTPS 8443							

Table 6 Port requirements for Gateway Client and Policy Manager servers (page 2 of 2)

EMC product	TCP port or Protocol	Notes for port settings	Direction open	Source -or- Destination	Application name	Communication (network traffic) type	Performed by authorized EMC Global Services personnel; Support objective (frequency)
Policy Manager	HTTP (configurable) Default = 8090		Inbound	from ESRS IP Clients (and customer browser)	Policy Manager service	Policy query (and policy management by customer)	N/A
	HTTPS 8443						
	SMTP 25		Outbound	to Customer email server		Action request	

Table 7 Port requirements for devices managed by Gateway Client (page 1 of 6)

EMC product	TCP port or Protocol	Notes for port settings	Direction open	Source -or- Destination	Application name	Communication (network traffic) type	Performed by authorized EMC Global Services personnel; Support objective (frequency)	
Atmos®	HTTPS ^a		Outbound	to Gateway Client	ConnectEMC	Service notification	NA	
	Passive FTP							
	SMTP			to Gateway Client or Customer SMTP server				
	22		Inbound	from Gateway Client	CLI (via SSH)	Remote support	Administration (occasional)	
	443				SecureWebUI		Troubleshooting (frequent)	
Avamar®	HTTPS ^a		Outbound	to Gateway Client	ConnectEMC	Service notification	NA	
	Passive FTP							
	SMTP			to Gateway Client or Customer SMTP server				
	22		Inbound	from Gateway Client	CLI (via SSH)	Remote support	Administration (occasional)	
	8543				AVInstaller			
	80,443, 8778, 8779, 8580, 8543, 9443, 7778, 7779, 7780, 7781, 8780, and 8781			Enterprise Manager		Troubleshooting (frequent)		
Celerra®	HTTPS ^a		Outbound	to Gateway Client	ConnectEMC	Service notification	Note: NAS code 5.5.30.x and earlier supports only FTP; NAS code 5.5.31.x supports both FTP and SMTP for connect home by using the Gateway Client.	
	Passive FTP							
	SMTP							
	All of: 80, 443, and 8000		Inbound	from Gateway Client	Celerra Manager (Web UI)	Remote support	Administration (occasional)	
	22				CLI (via SSH)		Troubleshooting (frequent)	
	23	This telnet port should be enabled <i>only</i> if SSH (port 22) cannot be used.			Telnet	Troubleshooting (rare) Use <i>only</i> if CLI cannot be used		

Table 7 Port requirements for devices managed by Gateway Client (page 2 of 6)

EMC product	TCP port or Protocol	Notes for port settings	Direction open	Source -of- Destination	Application name	Communication (network traffic) type	Performed by authorized EMC Global Services personnel: Support objective (frequency)
EMC Centera®	SMTP		Outbound	to Customer SMTP server	ConnectEMC	Service notification	N/A
	Both 3218 and 3682			from Gateway Client	EMC Centera Viewer	Remote support	Diagnostics (frequent)
	22				CLI (via SSH)		Troubleshooting (frequent)
CLARiiON® and CLARiiON portion of EDL	HTTPS ^a	Service notification for CLARiiON and EDL is supported only on centrally managed devices via a management server. Distributed CLARiiON devices (including EDL) use Gateway Client or Customer email server (SMTP) for service notifications.	Outbound	to Gateway Client	ConnectEMC	Service notification	N/A
	Passive FTP ^b				ConnectEMC, Navisphere® SP Agent		
	SMTP ^c						
	13456 22 (to run pling)		Inbound	from Gateway Client	KTCONS	Remote support	Troubleshooting (occasional)
	Both 80 and 443, or optionally (depending on configuration), both 2162 and 2163	For more information, refer to CLARiiON documentation.			Navisphere Manager; also allows Navisphere SecureCLI		Administration (frequent) Troubleshooting (frequent)
	9519				RemotelyAnywhere		
	5414				EMCRemote		
	All of: 6389, 6390, 6391, and 6392				Navisphere CLI		
60020		Remote Diagnostic Agent			Diagnostics (occasional)		
Navisphere Management Station	HTTPS ^a		Outbound	to Gateway Client	ConnectEMC	Service notification	N/A
	Passive FTP ^b				ConnectEMC, Navisphere SP Agent		
	SMTP ^c						
Connectrix® switch family	HTTPS ^a		Outbound	to Gateway Client	ConnectEMC or DialEMC	Service notification	N/A
	Passive FTP ^b						
	SMTP ^c						
	5414		Inbound	from Gateway Client	EMCRemote	Remote support	Troubleshooting (frequent)
Customer Management Station	5414		Inbound	From Gateway Client	EMCRemote	Remote support	Troubleshooting (frequent)
	9519				Remotely-Anywhere		
	3389				RemoteDesktop		
	80, 443, 8443				WebHTTPHTTP		
	22				CLI (via SSH)		

Table 7 Port requirements for devices managed by Gateway Client (page 3 of 6)

EMC product	TCP port or Protocol	Notes for port settings	Direction open	Source -of- Destination	Application name	Communication (network traffic) type	Performed by authorized EMC Global Services personnel; Support objective (frequency)
Data Domain	HTTPS		Inbound	from Gateway Client	Enterprise Manager	Remote support	Administration (occasional) Troubleshooting (frequent)
	HTTP						
	22		Inbound	from Gateway Client	CLI (via SSH)	Remote support	Administration (occasional) Troubleshooting (frequent)
	25		Outbound	to Customer SMTP server		Service notification	N/A
DL3D Engine	SMTP ^c		Outbound	to Customer SMTP server	CentOS	Service notification	N/A
	22		Inbound	from Gateway Client	CLI (via SSH)	Remote support	Troubleshooting (frequent)
	443	Secure Web UI					
DLm	HTTPS ^a		Outbound	to Gateway Client	ConnectEMC	Service notification	N/A
	Passive FTP ^b						
	SMTP ^c						
	22		Inbound	from Gateway Client	CLI (via SSH)	Remote support	Troubleshooting (frequent)
	80, 443, 8000	Celerra Manager					
	80,443	DLmConsole					
EDL Engine (except DL3D)	HTTPS ^a	Service notification for EDL is supported only on centrally managed devices via a management server. Distributed CLARiiON devices (including EDL) use Gateway Client or Customer email server (SMTP) for service notifications.	Outbound	to Gateway Client	ConnectEMC	Service notification	N/A
	Passive FTP ^b						
	SMTP ^c						
	22		Inbound	from Gateway Client	CLI (via SSH)	Remote support	Troubleshooting (frequent)
	11576	EDL Mgt Console					
Greenplum Data Computing Appliance (DCA) [®]	HTTPS ^a		Outbound	to Customer SMTP server	ConnectEMC	Service notification	NA
	Passive FTP						
	SMTP						
	22		Inbound	from Gateway Client	CLI (via SSH)	Remote support	Administration (occasional) Troubleshooting (frequent)
Invista [®] Element Manager	HTTPS ^a		Outbound	to Gateway Client	ConnectEMC	Service notification	N/A
	Passive FTP ^b						
	SMTP ^c						
Invista CPCs	5414		Inbound	from Gateway Client	EMCRemote	Remote support	Troubleshooting (frequent)
	All of: 80, 443, 2162, and 2163				Invista Element Manager and InvistaSecCLI		
	5201				ClassicCLI		

Table 7 Port requirements for devices managed by Gateway Client (page 4 of 6)

EMC product	TCP port or Protocol	Notes for port settings	Direction open	Source -Of-Destination	Application name	Communication (network traffic) type	Performed by authorized EMC Global Services personnel; Support objective (frequency)
Isilon®	HTTPS ^a	ESRS team highly recommends using CEC- HTTPS transport protocol as FTP and SMTP are plain text protocols.	Outbound	to Gateway Client	ConnectEMC	Service notification	NA
	Passive FTP						
	SMTP						
	Managed File Transfer (MFT) 8118	Within Isilon OneFS 7.1, the isi_gather_info script will send the Isilon log file back to EMC via MFT using port 8118 on the ESRS Gateway. All other Connect Homes will use ConnectEMC to send files to the Gateway using HTTPS, Passive FTP, or SMTP.			ISI-Gather Log Process	Configuration information	
	22		Inbound	from Gateway Client	CLI (via SSH)	Remote support	Administration (occasional)
	8080				WEBUI		Troubleshooting (frequent)
Recover-Point	SMTP ^c		Outbound	to Gateway Client		Service notification	N/A
	22		Inbound	from Gateway Client	CLI (via SSH)	Remote support	Troubleshooting (frequent)
	80, 443, and 7225				RecoverPoint Management GUI		
Switch–Brocade-B	22		Inbound	from Gateway Client	CLI (via SSH)	Remote support	Troubleshooting (frequent)
	23	This telnet port should be enabled <i>only</i> if SSH (port 22) cannot be used.			Telnet		Troubleshooting (rare) Use <i>only</i> if CLI cannot be used
Switch–Cisco	SMTP ^c		Outbound	to Customer SMTP server			N/A
	22	SSH must be enabled and configured.	Inbound	from Gateway Client	CLI (via SSH)	Remote support	Troubleshooting (frequent)
	23	This telnet port should be enabled <i>only</i> if SSH (port 22) cannot be used.			Telnet		Troubleshooting (rare) Use <i>only</i> if CLI cannot be used
Symmetrix®	HTTPS ^a		Outbound	to Gateway Client	ConnectEMC or DialEMC	Service notification	N/A
	Passive FTP ^b						
	SMTP ^c		Inbound	from Gateway Client	RemotelyAnywhere	Remote support	Troubleshooting (frequent)
	9519				EMCRemote		
	5414				SGBD/Swuch/Chat Server/Remote Browser/InlineCS		
	All of: 1300, 1400, 4444, 5555, 7000, 23003, 23004, and 23005						
ViPR	HTTPS ^a		Outbound	to Gateway Client	ConnectEMC	Service notification	N/A
	Passive FTP ^b						
	SMTP ^c		Inbound	from Gateway Client	CLI (via SSH)	Remote support	Troubleshooting (frequent)
	22				ViPR Management GUI		
	443, 4443, 80						

Table 7 Port requirements for devices managed by Gateway Client (page 5 of 6)

EMC product	TCP port or Protocol	Notes for port settings	Direction open	Source -Of-Destination	Application name	Communication (network traffic) type	Performed by authorized EMC Global Services personnel; Support objective (frequency)
VMAX® Cloud Edition (CE)	HTTPS ^a		Outbound	to Gateway Client	ConnectEMC	Service notification	NA
	Passive FTP ^b						
	SMTP ^c						
	22		Inbound	from Gateway Client	CLI (via SSH)	Remote support	Troubleshooting (frequent)
	443, 8443, 22, 80, 903, 8080, 10080, 10443, 902				VClient		Administration (frequent)
	443				WebHostLogAccess (Primary)		
	443				WebHostAccess		
	9443, 443, 80				WebVClient		
5480				vAppAccess (Primary)			
VNX®	HTTPS ^a		Outbound	to Gateway Client	ConnectEMC	Service notification	N/A
	Passive FTP ^b						
	SMTP ^c						
	13456		Inbound	from Gateway Client	KTCONS	Remote support	Troubleshooting (occasional)
	13456, 13457				RemoteKTrace		Administration (frequent)
	9519				Remotely-Anywhere		Troubleshooting (frequent)
	22				CLI (via SSH)		
	22				USM (VNX Control Station Device Client)		
	80, 443, 2162, 2163, 8000				Unisphere/USM/Navisphere SecureCLI		
6391, 6392, 60020				Remote Diagnostic Agent	Diagnostics (occasional)		
VNXe®	HTTPS ^a		Outbound	to Customer SMTP server	ConnectEMC	Service notification	NA
	Passive FTP						
	SMTP						
	22		Inbound	from Gateway Client	CLI (via SSH)	Remote support	Administration (occasional)
	80 and 443				Unisphere		Troubleshooting (frequent)
VPLEX	SMTP		Outbound	to Gateway Client	ConnectEMC	Service notification	N/A
	443		Inbound	from Gateway Client	Invista Element Manager	Remote support	Troubleshooting (frequent)
	22				CLI (via SSH)		Advanced troubleshooting (by EMC Symmetrix Engineering) (rare)

Table 7 Port requirements for devices managed by Gateway Client (page 6 of 6)

EMC product	TCP port or Protocol	Notes for port settings	Direction open	Source -or- Destination	Application name	Communication (network traffic) type	Performed by authorized EMC Global Services personnel; Support objective (frequency)
XtremIO	HTTPS ^a		Outbound	to Gateway Client	ConnectEMC	Service notification	N/A
	Passive FTP ^b						
	SMTP ^c		Inbound	from Gateway Client	CLI (via SSH)	Remote support	Troubleshooting (frequent)
	22, 80				XTREMIOGUI		
80, 443, 42502	<p>a. Use of HTTPS for service notifications is dependent on the version of ConnectEMC used by the managed device. Refer to product documentation. The default port for HTTPS is 443.</p> <p>b. During the ESRS-IP Windows installer execution, the value for Passive Port Range in IIS FTP is set to 21 and 5400 through 5413. This range indicates the data channel ports available for response to PASV commands. See RFC 959 for passive FTP definition. These ports are used for passive mode FTP of connect home messages as well as for the GWExt loading and output.</p> <p>During the ESRS-IP Linux installer execution, the installer autoconfigures FTP settings only if vsftpd is available on the system. The same port range as Windows will be set up in this case.</p> <p>c. Port 25 needs to be open to the ESRS gateway server or Customers SMTP server, only from the Fabric Manager Server or ECC. The protocol SMTP is assigned the service port 25, used for Outbound Service Notification to Gateway Client or email server.</p> <p>Linux Gateway installation autoconfigures SMTP service only if postfix is available on the system.</p>						

This chapter describes the ESRS configurations supported by EMC and provides recommendations for choosing a configuration and topology for your site. Topics include:

- ◆ Introduction 48
- ◆ Recommended ESRS configurations 51
- ◆ Other supported configurations 55
- ◆ Topology and network considerations 58
- ◆ About the Policy Manager 64
- ◆ About High Availability Gateway Clusters 67

Introduction

EMC recommends specific EMC Secure Remote Support component configurations. EMC supports, but does not recommend, certain other configurations. Both types of configurations are discussed in this chapter.

Note: In addition to the specifications described in the following sections, there are limits on the quantity of devices that can be safely managed on each server. There is a limit of 250 devices per Gateway Client server/Gateway Cluster (each CLARiiON counts as two devices) and 750 devices per Policy Manager. [Table 8 on page 50](#) provides detailed examples of device and server limits.

There are two main software components of ESRS that reside at a your site:

- ◆ ESRS Client (Gateway or Device)
- ◆ Policy Manager

ESRS Gateway Client

The ESRS Gateway Client is this the application installed on a dedicated customer-provided server or VMware/Hyper-V instance (or multiple servers/ESX servers or Hyper-V servers/instances for a High Availability Gateway Cluster configuration)

Policy Manager

The Policy Manager The Policy Manager application may reside on its own server/VM/Hyper-V instance, or may be co-located on an existing server (with dependencies). The Policy Manager may also be configured on multiple servers for redundancy. Policy Manager can also support standalone ESRS Device Clients in the customer's environment. Configuring Device Clients is addressed in the Device Clients' product documentation.

Note: Policy Manager is not supported on Hyper-V at this time.

Device limits

The Gateway Client and Policy Manager components of ESRS have the following device limits to help ensure reliable performance.

Gateway Client: The recommended device limit for each Gateway Client or Clustered High Availability Gateway Client is 250 devices. The device limit was developed by using remote session performance data and historical statistics about the number of remote sessions and devices in the field. By limiting the number of devices that can be deployed on a Gateway Client, remote servicing of equipment can be continued during periods when there might be numerous remote connections due to several concurrent problems.

Note: There is currently no software block that will stop the deployment of more than 250 devices. However, exceeding this recommended limit may cause an unacceptable level of throughput for remote connections during periods of peak usage. This can result in poor remote application performance, the inability to service some devices and/or the being unable to process and forward device connect homes in a timely manner. The performance and behavior of the Policy Manager may also be significantly impacted.

Policy Manager: The recommended device limit for each Policy Manager is 750 devices. This limit enables the Policy Manager to retain spare bandwidth that may be needed during times of high activity.



IMPORTANT

Exceeding the maximum device limits may cause performance degradation, resulting in remote access support limitations and a loss of connect home capabilities. Policy Manager Database failure / corruption which could result in the loss auditing of remote session approvals, connect home file uploads, configuration changes and Policy Manager access audits. Policy Manager database corruption may also result in the loss of Policy Manager configuration and have significant impact on EMC's ability to provide remote support.

Table 8 Gateway Client configuration examples for maximum devices

	Configuration	Maximum devices	Policy Manager	Total servers
Site 1	Clustered HA servers group 1	250	Server No. 1 (servicing 6 Gateway Clients, 750 devices)	7
	Clustered HA servers group 2	250		
	Clustered HA servers group 3	250		
	Clustered HA servers group 4	250	Server No. 2 (servicing 6 Gateway Clients, 750 devices)	7
	Clustered HA servers group 5	250		
	Clustered HA servers group 6	250		
	Total maximum devices	1500		14
Site 2	Single Gateway Client server 1	250	Server No. 1 (servicing 3 Gateway Clients, 750 devices)	4
	Single Gateway Client server 2	250		
	Single Gateway Client server 3	250		
	Single Gateway Client server 4	250	Server No. 2 (servicing 3 Gateway Clients, 750 devices)	4
	Single Gateway Client server 5	250		
	Single Gateway Client server 6	250		
	Total maximum devices	1500		8
Site 3 ^a	Single Client server 1 / co-located PM	250	(Co-located on Gateway Client 1, servicing 3 Gateway Clients, 750 devices)	3
	Single Gateway Client server 2	250		
	Single Gateway Client server 3	250		
	Single Client server 4 / co-located PM	250	(Co-located on Gateway Client 4, servicing 3 Gateway Clients, 750 devices)	3
	Single Gateway Client server 5	250		
	Single Gateway Client server 6	250		
	Total maximum devices	1500		6

a. The Site 3 example is not a recommended configuration, but may be used as a test configuration.

Recommended ESRS configurations

EMC has three recommended configurations for ESRS IP:

- ◆ High Availability Gateway Cluster and Policy Manager (Standalone or Redundant) (preferred configuration)
- ◆ Single Gateway Client Server and Policy Manager (Standalone or Redundant)
- ◆ Single Gateway Client Server with co-located Policy Manager (recommended for testing only)

The following section describes these recommended configurations.

High Availability Gateway Cluster and Policy Manager




Figure 3 Clustered HA Gateway Client servers and Policy Manager

EMC's preferred configuration for ESRS is the **High Availability Gateway Cluster and Policy Manager** configuration shown in [Figure 3 on page 51](#).

Once the cluster relationship is established, devices may be deployed on any of the clustered Gateway servers and are managed by *all* Gateway servers in the High Availability solution. Each server serves as a peer for the other servers in the cluster relationship. Each server monitors all devices, and any of the clustered servers can provide remote support access and/or connect home activity.

The Policy Manager provides auditing of connect homes and script execution on the ESRS Client. The Policy Manager also provides auditing and access control to managed devices. A Redundant Policy Manager is optional but highly recommended. It will enable you to manually fail over your backup Policy Manager database in the event that your primary Policy Manager becomes unavailable.

If you implement the High Availability Cluster and Policy Manager configuration, the Policy Manager will not be impacted by failure of the Gateway server hardware.

Note: Redundant Policy Manager is only supported on Policy Manager 2.02.1-xxx.

The **High Availability Gateway Cluster and Policy Manager** configuration has the following characteristics:

- ◆ **Number of required servers:** 3 (minimum), or 3 VMware instances on separate servers (provided that the minimum hardware requirements are met)
- ◆ **Pros:**
 - The Policy Manager provides auditing and access control for the solution.
 - The cluster configuration provides connect home and remote support connection redundancy.
 - In the event of a server hardware failure, the cluster configuration allows for easy recovery of the failed ESRS Client.
- ◆ **Con:** Multiple servers or VMware instances are required.

Single Gateway Client and Policy Manager

Easily upgraded to preferred configuration




Figure 4 Single Gateway Client server and Policy Manager

The **Single Gateway Client and Policy Manager** configuration shown in [Figure 4 on page 53](#) is designed for customers who initially want to utilize a single Gateway server with a separate Policy Manager server.

Note: This configuration does not provide High Availability. It does, however, provide an upgrade path to a High Availability configuration.

The **Single Gateway Client and Policy Manager** configuration has the following characteristics:

- ◆ **Number of required servers:** 2
- ◆ **Pro:**
 - Ease of upgrade from this configuration to a High Availability Gateway Cluster configuration (the preferred configuration)
 - Permits easy recovery from a failed Gateway
- ◆ **Con:** Single point of failure for the server, which can negatively impact connect home and remote access

If you upgrade from the single Gateway Client configuration to the High Availability Gateway Cluster configuration, upgrade tasks will include installation of the new servers and ESRS Client software. The new servers must be clustered to the original server and pointed to the same Policy Manager. Devices are then configured to utilize the other servers in the cluster for connect home failover.

Single Gateway Client server with co-located Policy Manager




Figure 5 Single Gateway Client server with co-located Policy Manager

The configuration shown in [Figure 5 on page 54](#) is sometimes used for initial certification (or testing) of ESRS.



IMPORTANT

This configuration does not provide High Availability, and is ONLY supported for test configurations and is not a recommended configuration for production.

The **Single Gateway Client server with co-located Policy Manager** configuration has the following characteristics:

- ◆ **Number of servers:** 1
- ◆ **Pro:** Only one server is required.
- ◆ **Con:** The single-server configuration is a single point of failure. This configuration should be used for test purposes only.

The tasks required to upgrade to a High Availability configuration would include: installation of a separate Policy Manager server, migration of current policies to the new Policy Manager, and establishment of the High Availability Gateway Cluster. The new Gateway Client server must be clustered to the original server, and both Gateway Clients must be pointed to the new standalone Policy Manager.

Note: Minimum recommended memory for Gateway with Collocated Policy Manager is 3 GB.

Other supported configurations

EMC recommends one of the three configurations described in “Recommended ESRS configurations” on page 51. However, EMC also supports the following configurations:

- ◆ High Availability Gateway Client servers without Policy Manager
- ◆ Single Gateway Client server without Policy Manager

This section provides details on these other supported configurations.




Figure 6 High Availability Gateway Client servers without Policy Manager

High Availability Gateway Client servers without Policy Manager

The **High Availability Gateway Client servers without Policy Manager** configuration shown in [Figure 6 on page 55](#) is supported by EMC. The configuration has the following characteristics:

- ◆ **Number of servers:** 2
- ◆ **Pros:**
 - This configuration can be upgraded to a High Availability Gateway Cluster with standalone Policy Manager (preferred configuration).
 - This configuration provides connect home and remote support connection redundancy.

- This configuration allows for easy recovery of the failed server in the event of a server hardware failure.

◆ **Con:**

No Policy Manager (therefore no access control or auditing).

If you decide to upgrade from this configuration to a configuration that includes a Policy Manager, installation and configuration will be required. Both Gateway Client servers must be pointed to the new Policy Manager.




Figure 7 Single Gateway Client server without Policy Manager

Single Gateway Client server without Policy Manager

The Single Gateway Client server without Policy Manager configuration shown in [Figure 7 on page 56](#) is supported by EMC.

The configuration has the following characteristics:

◆ **Number of servers:** 1

◆ **Pro:**

- This configuration can be upgraded to a recommended configuration.

◆ **Cons:**

- No Policy Manager (therefore no access control or auditing)
- Single point of failure for the Gateway Client server

If you decide to upgrade from this configuration to a configuration that includes a High Availability Gateway Cluster and a Policy

Manager, upgrade tasks will include installation and configuration of the Policy Manager, installation of the new Gateway Client, and establishment of the High Availability Gateway Cluster. The new Gateway Client server must be clustered to the original Gateway Client server, and both Gateway Client servers must be pointed to the new standalone Policy Manager. All deployed devices must have connect home configured for failover to the new Gateway server.

Topology and network considerations

Follow the recommendations and other information in this section when you are making decisions about your site topology.

Determining the quantity of Gateway Clients and Policy Managers

The quantity of independent ESRS Client solutions you install is determined by the total number of devices that you want to monitor.

There is a maximum number of monitored devices that can be managed by a single Gateway Client server (or HA clustered servers) and each Policy Manager:

- ◆ A single Gateway Client server (or a server in a High Availability cluster) can manage a maximum of 250 devices.
- ◆ A single Policy Manager can manage a maximum of 750 monitored devices.

Note: Each CLARiiON device serial number is deployed as two devices.

Thus, for *each* 250 or fewer monitored devices (where each CLARiiON counts as two devices), install one Gateway Client server (or multiple clustered servers), and one Policy Manager per three Gateway Client servers (or three sets of clustered servers). Examples are shown in [Table 8 on page 50](#).

Installing a separate Policy Manager server

EMC strongly recommends that you install the Policy Manager on a separate dedicated server on your internal production network.

This is recommended for the following reasons:

- ◆ **Easier access to the Policy Manager server**
You will be able to quickly log in to the Policy Manager server to respond to a remote access request or make changes to your device access or authorization rules.
- ◆ **Increased network security for the Policy Manager**
The Policy Manager is designed to be inaccessible to all third parties, including EMC. If you install the Policy Manager on a separate server inside your internal network, there is virtually no way for any third party to gain access to the server application.

Note: If you want to install a single Gateway Client server in your DMZ, you may co-locate the Policy Manager on this server. This configuration is recommended for testing purposes only, and is not recommended for production purposes. If you decide to use this configuration, you must ensure that the Policy Manager has bidirectional access to your internal network so that it can provide email notification and permit access to the Policy Manager application.

Protecting the Gateway Client server

There are no specific technical restrictions on the location of Gateway Client servers within the network. However, you should do the following:

- ◆ Provide firewall protection for your Gateway Client server.
- ◆ Block all network ports that are not required by ESRS.

Note: See [Table 6 on page 39](#) to identify the ports that should be opened.

Using proxy servers

ESRS supports the use of a proxy server for routing outbound Internet traffic from the ESRS Client to EMC. A list of tested proxy servers, protocols, and network configuration requirements is provided in [“Enabling proxy server for ESRS Client traffic to EMC” on page 35](#).

When EMC installs your ESRS software, your EMC Global Services professional will configure the Clients to route all outbound Internet traffic to the proxy server and to use only the port that you specify to send data to the proxy server. The proxy server must direct the Client transactions through the external firewall over port 443 and 8443.

Note: Port 8443 is not required for functionality, however without this port being opened, there will be a significant decrease in remote support performance, which will directly impact time to resolve issues on the end devices.

You are responsible for all proxy server configuration, rules, and troubleshooting needs resulting from ESRS preparation, installation, and continued operation of the ESRS Clients.



IMPORTANT

To ensure communication integrity, proxy servers and devices external to your DMZ must not perform any method of SSL checking on outbound or inbound IP traffic for ESRS traffic. SSL

checking is performed on outbound communication on customer devices (firewalls, proxies, Web traffic filtering appliances or applications, Web traffic shaping/load balancing, certificate verification or proxying)

Topology configurations

There are several options for locating the Gateway Clients and Policy Manager. This section provides details on several configurations.

The following topology diagrams represent a configuration of a High Availability Gateway Client with a Policy Manager.

The recommended Gateway Client configuration is shown in [Figure 8 on page 61](#). The Gateway Client is located on a private

management LAN (or VLAN), and the Policy Manager is located on the production network.




Figure 8 Gateway Client and Device Client / Management LAN configuration

Note: ESRS uses strict application IP and port mapping for connection to only the managed devices.

Another configuration is shown in [Figure 9 on page 62](#). In this configuration, the Gateway Client and Policy Manager are both located on your production LAN.




Figure 9 Gateway Client and Device Client / Production network configuration

Note: ESRS uses strict application IP and port mapping for connection to only the managed devices.

In Figure 10 on page 63, the Gateway Client server is located in your DMZ, while the Policy Manager is located on your production network.




Figure 10 Gateway Client and Device Client / DMZ configuration

Note: ESRS uses strict application IP and port mapping for connection to only the managed devices.

Note: This configuration is the most difficult to configure and maintain. It is extremely dependent on customer network management. Un-intended changes may have a significant impact on ESRS.

About the Policy Manager

The Policy Manager is the ESRS component that determines, for each access request, whether the request should be granted, denied, or forwarded elsewhere for a decision. The Policy Manager also creates and maintains audit logs for your site. These logs tell you which activities have occurred, when they occurred, and who performed them. If a service request is supplied as part of an access request, the Policy Manager will display the service request in the Notification email and in the audit of the request and approval or denial of the request.

Although a Policy Manager may be installed at any time, EMC recommends that it be installed at the time of the Gateway Client installation. The ESRS Configuration Tool is used to establish the relationship between the Policy Manager and the Gateway Client. The two are not automatically linked.



IMPORTANT

Installation of a Policy Manager is *highly recommended*. Without a Policy Manager, your ESRS site will not have access control or audit logging, and access will be “Always Allow.”

Redundant Policy Manager

For additional protection, EMC highly recommends installation of a Redundant Policy Manager. This will enable you to continue policy management operations if your Policy Manager becomes unavailable. If this occurs you would manually fail over to the Redundant Policy Manager.

Note: If you install a Redundant Policy Manager, you must set up an automated backup process for your Policy Manager database so that it can be restored onto the Redundant Policy Manager. Local Policy Manager Database backup is configured during Policy Manager installation.

Note: Redundant Policy Manager is only supported on Policy Manager 2.02.1-xxx.

Policy Manager authorization settings

There are three levels of authorization for remote access activity. ESRS monitors activities and responds according to the authorization settings:

- ◆ **Always Allow** — Use this setting if you want to always allow remote access for the activity.
- ◆ **Never Allow** — Use this setting if you want to always deny remote access for the activity.
- ◆ **Ask for Approval** — Use this setting if you want to require manual approval of remote access requests for the activity. Approval is performed by using the Policy Manager's web-based user interface.

Note: If NO policy is received from the Policy Manager for a device (including the Gateway Client itself) the effective default policy is Never Allow (Deny) access resulting in the device(s) being inaccessible. In the case of an ESRS Gateway Client, all communication to EMC will be halted and the Client becomes disabled for support access or connect homes.

Policy Manager failure

If the Policy Manager fails, certain default conditions apply. Some of these default conditions can be overridden. This section explains the default response and how to override the default response if desired.

Default response

If a Policy Manager server failure or communication failure occurs, policies are cached on the Gateway Client. The following default conditions will apply:

- ◆ An **Always Allow** or **Never Allow** policy setting will allow or deny the applicable activity request, just as the Policy Manager would have done.
- ◆ An **Ask for Approval** setting will time out, since the Policy Manager is not available to request and transmit approval. This will effectively deny the activity request.
- ◆ If a device is deployed while the Policy Manager is unavailable, the effective Policy is Never Allow (Deny) until a valid policy is received.

Overriding the default response

If remote access is required after a Policy Manager failure (when the setting is **Ask for Approval**), you may grant access by using the ESRS Configuration Tool to disable the Policy Manager connection on the Gateway Client(s).

The illustration in [Figure 11 on page 66](#) provides a view within the Configuration Tool on the Gateway Client. To remove Policy

Manager requirements, clear the Enable Remote Policy Manager checkbox and save the new setting by clicking Apply Settings.




Figure 11 Configuration Tool: Removing Policy Manager requirements

Clearing the Enable Remote Policy Manager checkbox causes Client policies to revert to **Always Allow**. This procedure also flushes any previously cached policy settings and audits.

Audit entries remain cached on the ESRS Client if the following conditions are met:

- ◆ If no changes have been made to ESRS configuration by the Configuration Tool
- ◆ If the ESRS Client service has not been restarted
- ◆ If the ESRS Client server has not been rebooted

If these conditions are met, the cached audit entries will be appended to the active audit log when the Policy Manager becomes available.

About not using a Policy Manager

If you do not use a Policy Manager, or if the Policy Manager is not actively configured with ESRS Clients, ESRS approves all remote access requests and does not provide any access control audit logging.

About High Availability Gateway Clusters

To ensure maximum remote support uptime for your site, EMC strongly recommends that you prepare a minimum of two servers on which EMC Global Services can install an ESRS Gateway Client for configuration as High Availability Cluster.

Each Gateway Client server in the High Availability cluster should be running the same version of the Gateway Client software. For example, if one of the Gateway Clients is running release 2.04 code, all of the other Gateway Clients in the cluster should also run release 2.04 code. This will ensure that all of the Gateway Clients in the cluster are able to communicate with all of the device types qualified in that code release.



IMPORTANT

A High Availability Gateway Cluster implementation provides multiple-server “active/active” server support. It does *not* perform an automated server failover. See details in this section.

Note: Each Gateway Client server must have Windows Terminal Services Remote Desktop enabled so that EMC Global Services can provide support via Webex if necessary. EMC does NOT have access to the ESRS Client through ESRS.

A High Availability Gateway Cluster server configuration requires a minimum of two dedicated servers. These servers actively and simultaneously monitor devices on their shared managed device list. They also share the handling of remote access session requests and connect home requests based on the configuration of the managed devices.

With a High Availability implementation, your Gateway Client servers implement an “active/active” solution, which eliminates the single-point-of-failure characteristic of a single-server configuration. The servers synchronize their managed device configuration information by relaying device list modifications to one another through the EMC ServiceLink application servers.

Devices are usually deployed and have Primary connect home configured to the Gateway Client server that is physically located closest to the device. Event notification is performed by that Gateway Client, unless a problem occurs with that server. In that case, another

server in the Gateway cluster performs the activity. Device monitoring for Support access connectivity is performed by ALL gateways in the Cluster. Remote access session management is performed by the first Gateway in the cluster that sends a heartbeat and responds to the access request.



CAUTION

CLARiiON, EDL, and VNX-Block devices in a distributed environment do not have High Availability functionality for connect home event notification. These devices use a non-resilient email client for sending a single message directly to EMC or the Gateway. If the message fails to reach EMC or the Gateway for any reason, no other notification attempts are made.

High Availability Gateway Cluster clients do not have failover

A High Availability Gateway Cluster provides operational redundancy, ensuring that at least one of the servers is always operational. The High Availability cluster also provides backup capacity, which is operational in advance of any failure.

However, it is important to understand that ESRS does not implement *failover* behavior.

If a server fails in a High Availability Gateway Cluster

If a Gateway Client server fails, the other Gateway Client servers in the cluster *already have* full responsibility. Also, when device-to-Gateway Client ratios are properly configured, the other servers have the capacity for all device monitoring, event notification, and remote access session management.

When the failed server comes back online, all ESRS Clients once again simultaneously monitor devices and share the handling of connect home and remote access session requests.

Failover behavior at the EMC device level

Failover of connect home is initiated at an EMC storage device

When appropriately configured, EMC device connect home applications supports clustered High Availability servers as defined by the Product implementation of ConnectEMC. When an EMC device supported by ESRS recognizes that connect home calls can not be received by the Gateways Client, it switches its connect home destination from its primary Gateway Client to an alternate.

Note: There is no failover for connect home messages by Gateway Client servers in Distributed VNX/CLARiiON environments. Only one message is sent by the EMC device. If the message fails for any reason, no attempt is made to resend the message.

About Single Gateway Client configurations

EMC provides you with the option of configuring a single Gateway Client server.

However, when you choose a single Gateway Client configuration:

- ◆ You do *not* have High Availability protection. If the server fails, remote connection is not possible.
- ◆ If a server or connection fails, EMC will not be notified of exception events on devices. As a result, EMC will not be able to provide remote support in a timely manner.

This chapter describes how you should work with your assigned EMC Global Services professionals to prepare your sites for installation of ESRS.

The chapter includes the following sections:

- ◆ Overview 72
- ◆ EMC coordination schedule 73

Additional information for specific information of Network; Operation System and ESRS application configuration are defined in the *EMC Secure Remote Support Gateway Operations Guide* and *EMC Secure Remote Support Policy Manager Operations Guide*. Consultation as to specifics may require contacting ESRS Customer Support.

Overview

This section provides information about site installation.

Coordination with EMC

Because EMC Secure Remote Support has both customer site components and EMC site components, your network, storage system, and security administration personnel must work closely with your EMC Global Services representatives to prepare your site for ESRS software installation.

As part of the software installation process, your EMC team may initiate multiple planning meetings with you to ensure that your onsite software installation is as fast and seamless as possible. You should also hold internal meetings to discuss your site configuration planning and documentation requirements.

For example, planning meetings could include the following meetings:

- ◆ An implementation kickoff meeting with your team and EMC Global Services and EMC Sales. This meeting would include a review of ESRS.
- ◆ A site configuration planning and documentation meeting with your network, storage, and security administration teams and EMC Global Services
- ◆ A final site installation planning and scheduling meeting with your network, storage, and security administration teams and EMC Global Services

For additional details, see [“EMC coordination schedule” on page 73](#).

Preparation work

In conjunction with your meetings with EMC, you should plan and execute the required preparation work. For more information on these requirements, refer to the following sections:

- ◆ [“Installing and configuring servers” on page 78](#)
- ◆ [“Configuring your network” on page 78](#)

EMC coordination schedule

Before installation of ESRS, you must provide EMC Global Services with the following information for configuring your ESRS software:

- ◆ Contact information for the people who will prepare your site for installation and support your hardware and software
- ◆ Specifications for the servers on which you plan to install the ESRS Client and Policy Manager applications
- ◆ Specifications for the number and types of devices to be managed by the Solution
- ◆ Specifications for the network configuration, network security policies, and Internet protocols that determine how devices, Gateway Client and Policy Manager servers, and EMC's ServiceLink servers communicate with one another within ESRS

Note: A Pre-site Checklist is available from your EMC Global Services representative or may be downloaded from the EMC Online Support Site (support.emc.com). The checklist will help you track and report the progress of your site preparation for ESRS.

Kickoff meeting

One of the first steps for a successful ESRS implementation is a review and implementation kickoff meeting with EMC Sales, EMC Global Services, or both.

At this meeting, you will:

1. **Review topology options** — The EMC team will provide an overview of the ESRS solution. You and the EMC team will discuss the possible site configuration options and review the necessary site requirements for your chosen configuration.
2. **Determine physical locations and resources** — You and the EMC team will identify physical locations for installing the Gateway Client and Policy Manager servers. You will identify the network, storage, and security personnel with in your organization responsible for:
 - Preparing your site for installation
 - Troubleshooting the customer-supplied hardware and software during installation

- Maintaining the customer-supplied hardware and software after installation

Note: EMC Global Services is not responsible for troubleshooting or resolving customer operating system or network issues. EMC Global Services is also not responsible for performing server operating system installation and configuration.

3. **Obtain EMC documentation and tools** — EMC Global Services will provide you with the following documentation and tools:
- *EMC Secure Remote Support Release Notes*
 - *EMC Secure Remote Support Technical Description*
 - *EMC Secure Remote Support Pre-Site Checklist* The checklist is to be completed with EMC Global Service assistance.
 - *EMC Secure Remote Support Site Planning Guide*
 - *EMC Secure Remote Support Port Requirements*
 - *EMC Secure Remote Support Gateway for Windows Operations Guide*
 - *EMC Secure Remote Support Customer Environment Check Tool for Windows Operations Guide*
 - *EMC Secure Remote Support Gateway for Linux Operations Guide*
 - *EMC Secure Remote Support Customer Environment Check Tool for Linux Operations Guide*
 - *EMC Secure Remote Support Policy Manager Release 2.02.1-xxx Operations Guide*

These documents and tools are also available for download from the EMC Online Support Site (support.emc.com).

Action items

EMC will order your ESRS kit — After a successful kickoff meeting, EMC Sales personnel will place an order for the ESRS kit (Model # ESRS-GW-200, Part # 953-002-303).

Note: ESRS Software **MUST** be installed in CSI for the Party Number/SiteID used for the installation prior to installing the ESRS Gateway software on a server. The Software and license are included with Embedded Device Clients

Note: If you are installing a High Availability Gateway Cluster, and the Gateway Client servers are at different sites, a separate kit must be ordered for each site (one kit per Site ID). You may use the same kit to install multiple instances of ESRS at the same site.

Begin your internal prep work — At this point, you should hold meetings with your network, storage system, and security administration teams. Review and be prepared to discuss the following items so that your team will be ready to make configuration decisions:

1. Review the following documents, as well as any additional information that EMC provides during the kickoff meeting:
 - *EMC Secure Remote Support Technical Description*
 - *EMC Secure Remote Support Site Planning Guide*
 - *EMC Secure Remote Support Port Requirements*
 - *EMC Secure Remote Support Gateway Operations Guide*
 - *EMC Secure Remote Support Policy Manager Operations Guide*
 - *EMC Secure Remote Support Customer Environment Check Tool Operations Guide*
2. Decide which EMC devices that you want EMC to support remotely via ESRS IP. [Chapter 1, "Overview,"](#) provides information on the device models that are available for support by the ESRS Solution.
3. Decide which ESRS site configuration option that you want to implement. [Chapter 3, "Configurations,"](#) provides information to help you make this decision.
4. Decide how you want to configure your network to accommodate ESRS components. [Chapter 3, "Configurations,"](#) provides information to help you make this decision.
5. Assign a resource to record the specifications of each component in your ESRS site configuration. Record the information in the *EMC Secure Remote Supports Pre-Site Checklist* that you obtain from your EMC Global Services professional or by download from the EMC Online Support Site (support.emc.com).

This editable checklist will help you record information about whichever of the following components apply to your configuration:

- Gateway Client server
- Policy Manager server
- Managed devices
- Proxy Server
- Email server for Policy Manager
- Network information for the connections between components

Note: Chapter 2, "Component Requirements," provides information on the minimum requirements for each customer-supplied component of ESRS.

6. Prepare a block diagram that depicts the planned server and device network configuration.

Configuration planning and documentation meeting

This will be the second meeting between your network, storage system, and security administration teams and EMC Global Services representatives. At this meeting, you will take the following actions:

1. **Review site plans** — You and your EMC Global Services representative will review and discuss your site configuration plans. You will use your completed *EMC Secure Remote Support Pre-Site Checklist* and block diagram as references.
2. **Create a prep-work schedule** — Your network, storage system, and security administration personnel will schedule the onsite pre-installation work that your teams must perform when setting up the Gateway Client or Policy Manager servers. You should also review with EMC a schedule for the onsite time required for EMC to perform any other changes required before the upcoming ESRS installation.
3. **Schedule device upgrades (if needed)** — You should inform EMC Global Services whether any EMC device upgrades are needed to make them compatible with the ESRS solution.

Note: Any upgrades that must be performed on storage devices in order to make them compatible with ESRS are not part of the ESRS deployment process.

Action items

Implement site configuration — Your network, storage system, and security administration teams should now implement the server and network preparation work that they scheduled during the second meeting with EMC Global Services, as detailed in the following sections.

Run initial site tests — EMC Global Services will provide you with the Customer Environment Check Tool utility (CECT). You must install this utility on each target Gateway Client and Policy Manager server. The utility verifies that your hardware, operating system, and network connectivity configurations meet ESRS requirements for connectivity to EMC and to the devices to be managed. Any adjustments must be documented within the pre-site checklist.

Provide the output of the Customer Environment Check Tool (CECT) and the documents for the previous page (completed Presite Check List and network diagram) to the EMC Global Services Representative for review.

Installing and configuring servers

Before the ESRS software is installed, you must install and configure the required operating system on your Gateway Client and Policy Manager servers. The *EMC Secure Remote Support Policy Manager Operations Guide* provides more information for a standard “C:” drive installation and for an operating system installation on a drive other than the standard.

Customer Environment Check Tool

EMC Global Services will provide you with the Customer Environment Check Tool utility (CECT), which tests your target Gateway Client servers and Policy Manager servers to verify that they meet hardware, operating system, and network configuration requirements.

The *EMC Secure Remote Support Customer Environment Check Tool Operations Guide* provides instructions for installing and running CECT.

Testing configuration

When you have finished configuring the operating system on the servers, you must run tests to make sure the servers are configured properly, and that the Internet Information Services (IIS) FTP and SMTP services are running normally on the Gateway Client servers.

Run **CECT** on all servers and ensure that each server passes all required tests before the ESRS installation date. **CECT** provides output logs which must be supplied to EMC Global Services.

Note: CECT requires that Microsoft .NET Framework 2.0 with SP1 (minimum) or Microsoft .NET Framework 3.5. Note that Microsoft .NET Framework 4.0 is not compatible at this time. Microsoft Visual C++ 2005 SP1 Runtime library is also required on the Gateway Client server.

Preparing network connections

Before EMC Global Services installs the ESRS software, you must ensure that your Client servers can communicate with EMC, with your Policy Manager server, and with your managed devices,. The **Customer Environment Check Tool** (CECT) has the capability to test and verify connectivity to EMC, the Policy Manager server, and with your devices to be managed by the ESRS client.

Configuring your network

To configure your network to support ESRS IP, take the following steps:

1. Ensure that your servers have unique addresses for all interfaces. Adhere to the following restrictions:

Note: All unused interfaces should be disabled.

- You must not use Port Address Translation. The Gateway Client servers, as well as all EMC devices to be managed through the Gateway Client, have services that listen for connection requests. These services will not work if Port Address Translation is employed.
 - You must not use Dynamic IP (DHCP) addresses for any ESRS component, whether they be Gateway Client servers, Policy Manager servers, or managed devices.
 - If you use DHCP to assign IP addresses to any Solution components (Gateway Client servers, Policy Manager servers, or managed devices), they must have “permanent reservation” IP addresses. Leases for any IP addresses that EMC devices are using must not expire. It is best to assign static IP addresses to those devices you plan to manage using ESRS.
2. Enable communication from each of your managed devices through your internal firewall to your Gateway Client servers over the required port connections.

Note: EMC is not and will not be responsible for the configuration of Firewalls and or Router/Switch Access Control Lists (ACLs) or Proxy Servers.

Note: Applications or Devices that perform Web traffic monitoring and/or traffic shaping, Certificate Checking/Verification from public sources, or Proxying certificates have been known to cause connectivity issues especially for remote support connections. These devices must also be properly configured to permit ESRS traffic to pass unhindered.

Note: Intrusion Detection Systems (IDS) have also had similar affects on the solution and these devices or applications must also be properly configured to permit ESRS traffic to pass unhindered

Note: The Customer Environment Check Tool may not be affected by these technologies that could impact the operability of ESRS during the installation or post install.

3. Follow these proxy server guidelines:

- **If you are *not* using a proxy server for outbound Internet traffic:**
Enable your ESRS Clients to communicate with the Internet through your external firewalls over ports 443 and 8443.
- **If you *are* using a proxy server for outbound Internet traffic:**
Enable your ESRS Clients to route all outbound traffic to the proxy server over the port required by your proxy server. The proxy server then needs to be able to connect outbound through the firewall over ports 443 and 8443.

Note: Neither the proxy server nor the firewall should do SSL checking. The customer is responsible for configuring Proxy Server.

4. Check that you have no existing constraints on your network that could interfere with communication between the following:
 - Gateway Client servers and Policy Manager servers
 - Gateway Client servers and EMC
 - Gateway Client servers and your managed devices

To ensure connectivity, use the port lists in [Table 6 on page 39](#) and [Table 7 on page 40](#). These tables show which ports need to be open for ESRS network traffic.

Testing network connections and port functionality

You must test all required connectivity between the following pairs:

- ◆ Gateway Client servers and EMC
- ◆ Gateway Client servers and your outbound proxy server (if any)
- ◆ Your outbound proxy server (if you use one) and EMC
- ◆ Gateway Client server and Policy Manager server (if applicable)
- ◆ Gateway Client servers and managed devices

EMC requires that you test all of these connections *before* the Installation Planning and Scheduling meeting. You should take to that meeting a list of any problems or failures that you have encountered.

Use the Customer Environment Check Tool (CECT) on each target Gateway Client server and Policy Manager server to verify that all required network connections are functioning properly. CECT will be run before doing any installation work in order to identify potential issues. It also should be run after installation is completed to ensure that the ESRS Client is functioning properly.

Installation planning and scheduling meeting

An installation and planning meeting should be the final meeting between customer network, storage, and security administration teams and EMC Global Services. At this meeting you should take the following actions:

1. **Review the Pre-site Checklist** — Your network, storage, and security administration teams should review your finalized pre-site checklist with EMC Global Services. The checklist must be complete and accurate since it will be used by EMC Global Services to perform ESRS installation. For an example of the checklist, see [Appendix A, “Pre-Site Checklist Example.”](#) An editable Microsoft Word document is available for download from the EMC Online Support Site (support.emc.com).
2. **Discuss and resolve problems** — Using your notes from network tests, as well as the output logs provided by the Customer Environment Check Tool (CECT), your team should discuss with EMC Global Services any problems that must be resolved before scheduling the ESRS installation.

Note that EMC Global Services is not responsible for:

- Troubleshooting or resolving customer operating system or network issues
 - Performing server operating system installation and configuration
 - Configuring proxy servers or firewalls
3. **Schedule the installation** — Work with EMC Global Services to schedule your ESRS installation date.
 4. **Run CECT again** — EMC recommends that you run the Customer Environment Check Tool (CECT) one more time just before your installation date. This will help determine if any changes have occurred to your environment between your initial site preparation work and the installation date.

Pre-Site Checklist Example

This appendix is adapted from *EMC Secure Remote Support Pre-Site Checklist*. The Pre-site Checklist is designed to help EMC and customer personnel successfully coordinate the installation and maintenance of ESRS at customer sites.

You need to complete your own checklist in coordination with your EMC Global Services professional. Topics in this appendix include:

- ◆ Contact information..... 84
- ◆ Environment specifications 86
- ◆ Checklist for installation visit readiness 87
- ◆ Ports opened for Gateway Client operation 96

Contact information

Site information

Length of engagement	Installation date	Completion date

Site function	Site name	Site ID	Locations
Primary			
Secondary (if applicable)			

Site contacts

Contacts	Company	Role	Phone numbers	Email

Gateway Client / Policy Manager server details

Type	Sales order number	Serial number	Version	Location	Install drive/path
Primary Gateway Client					
Additional Gateway Client					
Additional Gateway Client					
Primary Policy Manager					
Additional Policy Manager					

ESRS managed devices

EMC products (managed devices)	Serial number	Location	Connect Home method	IP address	Date deployed

EMC products (managed devices)	Serial number	Location	Connect Home method	IP address	Date deployed

Environment specifications

Network

Proxy server IP address/port	<i>(optional)</i>	
Proxy server username	<i>(optional)</i>	
Proxy server password	<i>(optional)</i>	
Network Address Translation (NAT) IP?		
Are ports 443 and 8443 open?		
Customer IP address ranges and customer subnet masks (device LANs)		
Client Server IP address (Internal/External)		
Is DHCP disabled?		
Is ESRS IP Client server in a DMZ?		
Is Client server inside customer network, and is customer using a proxy forwarder?		
Type of proxy server: Auto/HTTP/SOCKS		
Address (domain name or IP) of email server		
Admin email address		
Notification email address		

Gateway Client server

Equipment name	
Type	
Dual NIC cards available?	
IP address (1) / used for	
IP address (2) / used for	
Administrator rights	
Username	
Password	

Policy Manager server

Processor size, memory, drive size, free	
Dual NIC cards available?	
IP address / DNS name (1) used for	
IP address / DNS name (2) used for	
Windows Task Scheduler: Running unrestricted (so that Policy Manager backups)	
Is port 8090 or 8443 open? Non-default port?	
Enable SSL communication with Client	

Checklist for installation visit readiness

Use this checklist with the **Customer Environment Check Tool** (described in *EMC Secure Remote Support Customer Environment Check Tool Operations Guide*).

Readiness item	References	OK?	Exception / notes
ESRS IP Software Kit (Model: ESRS-GW-200; Part:953-002-303)			
Has the software kit been ordered? (A kit is needed for each physical site if a High Availability Gateway Cluster is being installed at multiple sites.)			
Gateway Client servers are built and ready			
Supported operating system installed			
Windows Time Zone set to local time zone			
Internet Explorer 6.0+ installed			
Microsoft.NET Framework Version 2.0 with SP1 (minimum) or Microsoft .NET Framework 3.5 installed (Microsoft .NET Framework 4.0 is not compatible)			
Microsoft Visual C++ 2005 SP 1 Runtime library			
IIS installed and configured including AdminScripts			
Server allows for user account notification			
Server attached to network in DMZ/other			
Network personnel verifies that server can route to internal devices (internal Gateway)			
Network personnel verifies that server can route to Internet (internal Gateway Client)			
The Customer Environment Check Tool has been run and tests pass, otherwise note exceptions and follow-up plan for All Gateway and Policy Manager servers			
Policy Manager server is built and ready			
Supported operating system installed			
Windows Time Zone set to local time zone			
Internet Explorer 6.0+ installed			

Readiness item	References	OK?	Exception / notes
Windows .NET Framework Version 2.0 with SP1 (minimum) or Microsoft .NET Framework 3.5 is required to run the Customer Environment Check Tool (CECT) (Microsoft .NET Framework 4.0 is not compatible)			
Server is on the appropriate network			
Network personnel verifies that server can route to default ESRS IP Client			
The Customer Environment Check Tool has been run and tests pass, otherwise note exceptions and follow-up plan			
EMC database			
All managed devices are in EMC database with a status of "installed"			
ESRS Site ID and P/N (953-001-994) in EMC database, with a status of "installed"			
Customer network and security external			
External IP Solution/firewalls allow 443 and 8443 outbound (Site A and B)			
No SSL checking performed on outbound communications by customer or ISP			
Internal IP Solution/firewalls opened up all appropriate ports for remote access connectivity (Site A)			
Atmos ports open			
Avamar ports open			
Celerra ports open			
EMC Centera ports open			
CLARiiON ports open			
Connectrix ports open			
Connection Home / FTP (passive ports open) Inbound to Gateway Client			
Customer Management Station ports open			
Data Domain ports open			
DLM ports open			
EDL ports open			
Greenplum DCA ports open			
Invista ports open			
Isilon ports open			
RecoverPoint port open			
Switch-Brocade-B ports open			
Switch-Cisco ports open			

Readiness item	References	OK?	Exception / notes
Symmetrix ports open			
ViPR ports open			
VMAX Cloud Edition (CE) ports open			
VNX ports open			
VNXe ports open			
VPLEX ports open			
XtremIO ports open			
Internal IP Solutions/firewalls opened up all appropriate ports for remote access connectivity (Site B)			
Atmos ports open			
Avamar ports open			
Celerra ports open			
EMC Centera ports open			
CLARiiON ports open			
Connectrix ports open			
Connection Home / FTP (passive ports open) Inbound to Gateway Client			
Customer Management Station ports open			
Data Domain ports open			
DLm ports open			
EDL ports open			
Greenplum DCA ports open			
Invista ports open			
RecoverPoint port open			
Switch-Brocade-B ports open			
Switch-Cisco ports open			
Symmetrix ports open			
ViPR ports open			
VMAX Cloud Edition (CE) ports open			
VNX ports open			
VNXe ports open			
VPLEX ports open			
XtremIO ports open			
Device readiness complete (Site A)			
Atmos devices addressed			
Atmos devices physically connected to network			
Atmos devices updated for network			
Problems / failures of above noted			

Readiness item	References	OK?	Exception / notes
Avamar devices addressed			
Avamar devices physically connected to network			
Avamar devices updated for network			
Problems / failures of above noted			
Celerra devices addressed			
Celerra devices physically connected to network			
Celerra devices updated for network			
Problems / failures of above noted			
EMC Centera devices addressed			
EMC Centera devices physically connected to network			
EMC Centera devices updated for network			
Problems / failures of above noted			
CLARiiON devices addressed			
CLARiiON devices physically connected to network			
CLARiiON devices updated for network			
Problems / failures of above noted			
Connectrix devices addressed			
Connectrix devices physically connected to network			
Connectrix devices updated for network			
Problems / failures of above noted			
Customer Management Station devices addressed			
Customer Management Station devices physically connected to network			
Customer Management Station devices updated for network			
Problems / failures of above noted			
Data Domain devices addressed			
Data Domain devices physically connected			
Data Domain devices updated for network			
Problems / failures of above noted			
DLM devices addressed			
DLM devices physically connected to network			
DLM devices updated for network			

Readiness item	References	OK?	Exception / notes
Problems / failures of above noted			
EDL devices addressed			
EDL devices physically connected to network			
EDL devices updated for network			
Problems / failures of above noted			
Greenplum DCA devices addressed			
Greenplum DCA devices physically connected to network			
Greenplum DCA devices updated for network			
Problems / failures of above noted			
Invista devices addressed			
Invista devices physically connected to network			
Invista devices updated for network			
Problems / failures of above noted			
Isilon devices addressed			
Isilon devices physically connected to network			
Isilon devices updated for network			
Problems / failures of above noted			
RecoverPoint devices addressed			
RecoverPoint devices physically connected to network			
RecoverPoint devices updated for network			
Problems / failures of above noted			
Switch-Brocade-B devices addressed			
Switch-Brocade-B devices physically connected to network			
Switch-Brocade-B devices updated for network			
Problems / failures of above noted			
Switch-Cisco devices addressed			
Switch-Cisco devices physically connected to network			
Switch-Cisco devices updated for network			
Problems / failures of above noted			
Symmetrix devices addressed			

Readiness item	References	OK?	Exception / notes
Symmetrix devices physically connected to network			
Symmetrix devices updated for network			
Problems / failures of above noted			
ViPR devices addressed			
ViPR devices physically connected to network			
ViPR devices updated for network			
Problems / failures of above noted			
VMAX Cloud Edition (CE) devices addressed			
VMAX Cloud Edition (CE) devices physically connected to network			
VMAX Cloud Edition (CE) devices updated for network			
Problems / failures of above noted			
VNX devices addressed			
VNX devices physically connected to network			
VNX devices updated for network			
Problems / failures of above noted			
VNXe devices addressed			
VNXe devices physically connected to network			
VNXe devices updated for network			
Problems / failures of above noted			
VPLEX devices addressed			
VPLEX devices physically connected to network			
VPLEX devices updated for network			
Problems / failures of above noted			
XtremIO devices addressed			
XtremIO devices physically connected to network			
XtremIO devices updated for network			
Problems / failures of above notes			
Device readiness complete (Site B)			
Atmos devices addressed			
Atmos devices physically connected to network			
Atmos devices updated for network			

Readiness item	References	OK?	Exception / notes
Problems / failures of above noted			
Avamar devices addressed			
Avamar devices physically connected to network			
Avamar devices updated for network			
Problems / failures of above noted			
Celerra devices addressed			
Celerra devices physically connected to network			
Celerra devices updated for network			
Problems / failures of above noted			
EMC Centera devices addressed			
EMC Centera devices physically connected to network			
EMC Centera devices updated for network			
Problems / failures of above noted			
CLARiiON devices addressed			
CLARiiON devices physically connected to network			
CLARiiON devices updated for network			
Problems / failures of above noted			
Connectrix devices addressed			
Connectrix devices physically connected to network			
Connectrix devices updated for network			
Problems / failures of above noted			
Customer Management Station devices addressed			
Customer Management Station devices physically connected to network			
Customer Management Station devices updated for network			
Problems / failures of above noted			
Data Domain devices addressed			
Data Domain devices physically connected			
Data Domain devices updated for network			
Problems / failures of above noted			
DLM devices addressed			
DLM devices physically connected to network			

Readiness item	References	OK?	Exception / notes
DLM devices updated for network			
Problems / failures of above noted			
EDL devices addressed			
EDL devices physically connected to network			
EDL devices updated for network			
Problems / failures of above noted			
Greenplum DCA devices addressed			
Greenplum DCA devices physically connected to network			
Greenplum DCA devices updated for network			
Problems / failures of above noted			
Invista devices addressed			
Invista devices physically connected to network			
Invista devices updated for network			
Problems / failures of above noted			
Isilon devices addressed			
Isilon devices physically connected to network			
Isilon devices updated for network			
Problems / failures of above noted			
RecoverPoint devices addressed			
RecoverPoint devices physically connected to network			
RecoverPoint devices updated for network			
Problems / failures of above noted			
Switch-Brocade-B devices addressed			
Switch-Brocade-B devices physically connected to network			
Switch-Brocade-B devices updated for network			
Problems / failures of above noted			
Switch-Cisco devices addressed			
Switch-Cisco devices physically connected to network			
Switch-Cisco devices updated for network			
Problems / failures of above noted			
Symmetrix devices addressed			

Readiness item	References	OK?	Exception / notes
Symmetrix devices physically connected to network			
Symmetrix devices updated for network			
Problems / failures of above noted			
ViPR devices addressed			
ViPR devices physically connected to network			
ViPR devices updated for network			
Problems / failures of above noted			
VMAX Cloud Edition (CE) devices addressed			
VMAX Cloud Edition (CE) devices physically connected to network			
VMAX Cloud Edition (CE) devices updated for network			
Problems / failures of above noted			
VNX devices addressed			
VNX devices physically connected to network			
VNX devices updated for network			
Problems / failures of above noted			
VNXe devices addressed			
VNXe devices physically connected to network			
VNXe devices updated for network			
Problems / failures of above noted			
VPLEX devices addressed			
VPLEX devices physically connected to network			
VPLEX devices updated for network			
Problems / failures of above noted			
XtremIO devices addressed			
XtremIO devices physically connected to network			
XtremIO devices updated for network			
Problems / failures of above noted			
All items above have been checked and completed			
Exceptions have been reviewed			

Ports opened for Gateway Client operation

Product	Application	Port
Atmos		
Avamar		
Celerra		
EMC Centera		
CLARiiON		
Connectrix Manager		

Product	Application	Port
Customer Management Station		
Data Domain		
DLM		
EDL		
Greenplum DCA		
Invista		

Product	Application	Port
Ison		
RecoverPoint		
Switch-Brocade-B		
Switch-Cisco		
Symmetrix		
ViPR		
VMAX Cloud Edition (CE)		

Product	Application	Port
VNX		
XtremIO		
VNXe		
VPLEX		
Gateway		
Policy Manager		

This glossary contains terms related to remote support and ESRS.

A

access See *Remote Access*.

C

connect home Connecting from a remote site to EMC's support network.

Client See *Gateway Client* or *Device Client*.

Customer Environment Check Tool (CECT) A utility that verifies that a candidate server meets the hardware, software, and network configuration requirements for a successful Gateway Client and Policy Manager software installation.

D

Device Client A dedicated ESRS client that resides on a single device and has similar functionality to a Gateway Client for connect home and remote support.

DMZ Demilitarized zone — Device used to secure an internal network from unauthorized external access.

Dynamic IP address An address that is assigned by the access device by which the user's host connects over a dialup telephone line or by a set-top box for an IP over cable network.

E**EMC Online Support Site**

Web-based access on support.emc.com to documentation, downloads, and support information for EMC customers and internal EMC users.

ESRS

EMC Secure Remote Support (ESRS), installed on a Gateway Client server, provides automated connect home and remote support activities through an IP-based solution enhanced by a comprehensive security system.

F**failover**

The capability to switch over automatically to a standby server upon the failure or abnormal termination of the previously active server. Failover happens without human intervention and generally without warning.

firewall

A hardware or software device that is configured to permit, deny, or proxy data through a computer network which has different levels of trust.

FTP

File Transfer Protocol — Used to transfer data from one computer to another, over the Internet or through a network.

G**Gateway Client**

An ESRS software component that is installed on a customer-supplied dedicated server (or servers) or VMware instance. The servers act as the single point of entry and exit for all IP-based EMC remote notification and remote support activity.

I**IIS**

Microsoft Windows Internet Information Services lockdown tool — Functions by turning off unnecessary features, thereby reducing areas available to attackers.

P**Policy Manager**

An ESRS software component that is installed on a customer-supplied server or servers. It enables customizable control

of remote access to customer devices and maintains an audit log of remote connections.

proxy server

A server (a computer system or an application program) which services the request of its clients by forwarding request to other servers. A client connects to the proxy server, requesting some service, such as a file, connection, web page, or other resource, available from a different server. The proxy server provides the resource by connecting to the specified server and requesting the service on behalf of the client. A proxy server may optionally alter the client's request or the servers's response, and sometimes it may serve the request without contacting the specified server.

R**remote access**

Communication with a processing device from a remote location through a data link.

S**Secure Sockets Layer (SSL) port**

A port that uses cryptographic protocols to provide secure Internet communications for data transfers.

SMTP

Simple Mail Transfer Protocol — The de facto standard for email transmissions across the Internet.

T**topology**

Network configuration, including firewalls, servers, devices, and ports used for communication between all devices.

A

AES encryption 19
architecture 16
Atmos 21, 40
authorization settings 64
Avamar 21, 40

B

Brocade switches 22, 43

C

CECT See Customer Environment Check Tool
Celerra 21, 40
Centera 21, 41
checklist, pre-site 83
Cisco switches 22, 43
CLARiiON 21, 41
co-located gateway client and Policy Manager
 requirements 32
Configuration Tool 18
configurations 47
 network 78
 recommended 51
 supported 55
connect home 37
connectivity testing 80
Connectrix 41
Connectrix Manager 21
Customer Environment Check Tool (CECT) 77,
 78, 80, 81
Customer Management Station 41
customer responsibilities 24

D

Data Domain 21, 42
Device Client 101
Device Clients 48
device limits 49
device upgrades 77
devices supported 21
devices, maximum number 58
DHCP 35
Disk Library (EDL) 21
DLm 21, 42
documents, ESRS 75
dynamic IP addresses 79

E

EDL 21, 42
Embedded ESRS Device client 18
EMC responsibilities 25
environment 21
ESRS
 documents 75
 software kit 74
ESRS Gateway Client 48

F

failover 68

G

Gateway Client 18, 38, 48, 60
 requirements 28
Greenplum Data Computing Appliance (DCA)
 42

Greenplum DCA 21

H

High Availability Gateway Clusters 67
 HTTP 36
 HTTPS 36

I

installation 72
 Invista 22, 42
 IP addresses, dynamic 34
 Isilon 22, 43

L

local users and groups 30

M

meetings
 configuration planning and documentation 77
 installation planning and scheduling 81
 kickoff 73
 memory requirements 29

N

networks
 configuring 78
 connections, testing 80
 ports, blocking 59
 requirements 34

P

people resources, identifying 73
 physical locations, determining 73
 planning meetings See meetings
 Policy Manager 18, 48, 58, 64
 failure 65
 requirements 31
 policy settings 64
 Port Address Translation 34
 port requirements 39
 prep-work schedule 77
 Pre-site Checklist 73, 81, 83

processor requirements 29
 Provisioning Tool 18
 proxy servers
 enabling 35
 guidelines 79
 protocols 36
 tested 36
 using 59

R

RecoverPoint 22, 43
 Redundant Policy Manager 19, 64
 remote access 64
 requirements
 co-located gateway client and Policy Manager 32
 Gateway Client 28
 memory 29
 networks 34
 Policy Manager 31
 port 39
 processor 29
 responsibilities
 customer 24
 EMC 25

S

server requirements 28
 servers
 requirements, hardware and OS 28
 types of 28
 single Gateway server 69
 site installation 72
 site planning process 25
 site plans 77
 site tests, initial 77
 software kit 74
 storage 29
 supported devices 20, 21
 Symmetrix 22, 43

T

testing network connections 80
 testing, connectivity 80
 topology 58, 60, 73

U

upgrading devices 20

V

ViPR 22, 43

VMAX Cloud Edition (CE) 22, 44

VMware 33

VNX 22, 44

VNX Control Station 22

VNXe 22

VPLEX 22, 44

X

XtremIO 23, 45

